



**ENVIRO-TEC**

**VERTICAL HI-RISE FAN COILS SERIES B**

**INSTALLATION, OPERATION & MAINTENANCE**

Supersedes: ET115.24-NOM4 (820)

Form ET115.24-NOM4 (1220)

**MODELS VHC/VHS/VHM VERTICAL HI-RISE  
VHA/VHB TANDEM MASTER & TANDEM SLAVE**



# IMPORTANT!

## READ BEFORE PROCEEDING!

### GENERAL SAFETY GUIDELINES

This equipment is a relatively complicated apparatus. During rigging, installation, operation, maintenance, or service, individuals may be exposed to certain components or conditions including, but not limited to: heavy objects, refrigerants, materials under pressure, rotating components, and both high and low voltage. Each of these items has the potential, if misused or handled improperly, to cause bodily injury or death. It is the obligation and responsibility of rigging, installation, and operating/service personnel to identify and recognize these inherent hazards, protect themselves, and proceed safely in completing their tasks. Failure to comply with any of these requirements could result in serious damage to the equipment and the property in

which it is situated, as well as severe personal injury or death to themselves and people at the site.

This document is intended for use by owner-authorized rigging, installation, and operating/service personnel. It is expected that these individuals possess independent training that will enable them to perform their assigned tasks properly and safely. It is essential that, prior to performing any task on this equipment, this individual shall have read and understood the on-product labels, this document and any referenced materials. This individual shall also be familiar with and comply with all applicable industry and governmental standards and regulations pertaining to the task in question.

---

## SAFETY SYMBOLS

The following symbols are used in this document to alert the reader to specific situations:



*Indicates a possible hazardous situation which will result in death or serious injury if proper care is not taken.*



*Identifies a hazard which could lead to damage to the machine, damage to other equipment and/or environmental pollution if proper care is not taken or instructions and are not followed.*



*Indicates a potentially hazardous situation which will result in possible injuries or damage to equipment if proper care is not taken.*



*Highlights additional information useful to the technician in completing the work being performed properly.*



*External wiring, unless specified as an optional connection in the manufacturer's product line, is not to be connected inside the control cabinet. Devices such as relays, switches, transducers and controls and any external wiring must not be installed inside the micro panel. All wiring must be in accordance with ENVIRO-TEC's published specifications and must be performed only by a qualified electrician. ENVIRO-TEC will NOT be responsible for damage/problems resulting from improper connections to the controls or application of improper control signals. Failure to follow this warning will void the manufacturer's warranty and cause serious damage to property or personal injury.*

## SAFETY CONSIDERATIONS

The equipment covered by this manual is designed for safe and reliable operation when installed, operated, and maintained within its' design specifications. To avoid personal injury or damage to equipment or property during installation, operation, and maintenance of this equipment, it is essential that these functions be performed by qualified, experienced personnel using good judgment and safe practices. See the following cautionary statements.



**ELECTRICAL SHOCK HAZARDS.** All power must be disconnected prior to installation and servicing of this equipment. More than one power source may be present. Disconnect all power sources to avoid electrocution or shock injuries.



**MOVING PARTS HAZARDS.** Power must be disconnected from the motor and blower prior to opening access panels. Motors can start automatically, and more than one power source may be present. Disconnect all power and control circuits prior to servicing to avoid serious crushing or dismembering injuries.



Electric resistance heating elements may start automatically. Disconnect all power and control circuits, and allow the elements to cool before servicing. Again, more than one power source may be present.



**HOT PARTS HAZARDS.** Hot water and steam heating coils operate at temperatures that will cause severe burn injury. Some systems will continue to allow circulation of hot water, even with all control circuits deenergized. Before performing service at or near any heating coil, piping, or valve package component, disconnect all power and close all isolation valves, and allow the equipment to cool. As previously mentioned, more than one power source may be present.



Check that the unit assembly and component weights can be safely supported by rigging and lifting equipment.



All assemblies must be adequately secured during lifting and rigging by temporary supports and restraints until equipment is permanently fastened and set in its final location.



All unit temporary and permanent supports must be capable of safely supporting the equipment's weight and any additional live or dead loads that may be encountered. All supports must be designed to meet applicable local codes and ordinances.



*All fastening devices must be designed to mechanically lock the assembly in place without the capability of loosening or breaking away due to system operation and vibration.*



*Secure all dampers when servicing damper, actuator or linkages. Dampers may activate automatically, disconnect control circuits to avoid injury.*



*Protect adjacent flammable materials when brazing, Use flame and heat protection barriers where needed. Have fire extinguisher available and ready for immediate use.*



*Never wear bulky or loose fitting clothing when working on any mechanical equipment. Gloves should only be worn when required for proper protection from heat or other possible injury. Safety glasses or goggles should always be worn when drilling, cutting, or working with chemicals such as refrigerants or lubricants.*




*Never pressurize any equipment beyond specified test pressures. Always pressure test with some fluid or inert gas such as clear water or dry nitrogen on refrigeration systems to avoid possible damage or injury in the event of a leak or component failure during testing.*



*The manufacturer assumes no responsibility for personal injury or property damage resulting from improper or unsafe practices during the handling, installation, service, or operation of any equipment.*

### VH SERIES B FEATURES

## SEE SECTION 6 - Dimensional Data FOR DIMENSIONAL DRAWINGS



Note: Some optional items are included with other features.

## TABLE OF CONTENTS

<b>SECTION 1 - RECEIPT &amp; INSTALLATION .....</b>	<b>8</b>
Preface .....	8
Unpacking & Inspection .....	8
Ship Loose Items .....	8
Handling & Installation .....	9
Cooling/Heating Medium Connections .....	9
Flex Hose .....	11
Factory Installed Risers .....	11
Factory Furnished, Field Installed Risers .....	12
Field Furnished and Installed Piping or Risers .....	13
Riser Connection .....	13
Ductwork Connections .....	14
Dual Air Discharge Units .....	14
Field Reconfigurable Risers and Discharge Openings.....	15
Riser Reconfiguration .....	15
Discharge Opening Reconfiguration .....	15
Wall Framing .....	16
Tandem Master & Tandem Slave Unit Installation .....	16
Outside Air Connection .....	17
Manual Outside Air Damper .....	17
Motorized Outside Air Damper .....	17
Electrical Connections Shock / Electrical Hazards.....	17
Thermostats .....	18
 <b>SECTION 2 - START-UP.....</b>	 <b>19</b>
General .....	19
Cooling/Heating System .....	19
Air System Balancing .....	20
Water System Balancing .....	20
Controls Operation .....	20
 <b>SECTION 3 - NORMAL OPERATION &amp; PERIODIC MAINTENANCE.....</b>	 <b>21</b>
General .....	21
Motor/Blower Assembly .....	21
Coil .....	21
Electric Resistance Heater Assembly.....	21
Electrical Wiring & Controls .....	22
Valves & Piping .....	22
Filters, Throwaway .....	23
Drain .....	23
Optional Removable Drain Pan .....	23
Replacement Parts .....	23
 <b>SECTION 4 - INSPECTION, INSTALLATION &amp; START-UP CHECKLIST.....</b>	 <b>24</b>
 <b>SECTION 5 - TROUBLESHOOTING.....</b>	 <b>26</b>

## TABLE OF CONTENTS (CONT'D)

<b>SECTION 6 - DIMENSIONAL DATA</b> .....	<b>29</b>
Vertical Hi-Rise Tandem Units	
VHA/VHB Installation Instructions .....	53
Receipt & Initial Installation .....	53
Temperature .....	56
 <b>APPENDIX - COMPONENT INSTALLATION, OPERATION &amp; MAINTENANCE MANUALS</b> .....	 <b>57</b>

## SECTION 1 - RECEIPT & INSTALLATION

### PREFACE

ENVIRO-TEC fan coils represent a prudent investment which can, with proper installation, operation, and regular maintenance, give trouble-free operation and long service.

Equipment is initially protected under the manufacturers' standard warranty; however, this warranty is provided under the condition that the steps outlined in this manual for initial inspection, proper installation, regular periodic maintenance, and everyday operation of the equipment be followed in detail. This manual should be fully reviewed in advance of any actual work being done on the equipment. Should any questions arise, please contact your local Sales Representative or the factory BEFORE proceeding.

The equipment covered by this manual is available with a vast variety of options and accessories. Consult the approved unit submittal, order acknowledgement, and other manuals for details on the options and accessories provided with the equipment on each project.

### UNPACKING & INSPECTION

All units are carefully inspected at the factory throughout the manufacturing process under a detailed quality assurance program. All factory furnished major components and subassemblies are carefully tested for proper operation and verified to be in full compliance with the customer order and quality assurance documents.

Each unit is then carefully packaged for shipment to avoid damage during normal transport and handling. The equipment must be stored in a dry place in the proper orientation as marked on the packaging.

All shipments are made F.O.B. factory and it is the responsibility of the receiving party to inspect the equipment upon arrival. Any obvious damage to the packaging and/or its contents should be recorded on the bill of lading and a claim should be filed with the freight carrier.

After determining the condition of the unit's exterior, carefully remove each unit from the packaging and inspect for hidden damage. At this time, check to make sure that "ship loose" items such as grilles, decorator panels, and thermostats are accounted for. Any hidden damage should be recorded and immediately reported to the carrier, and a claim filed as before. In the event a claim for shipping damage is filed, the unit, shipping package, and all packing must be retained for physical inspection by the freight carrier. All equipment should be stored in the factory shipping package with internal packing in place until installation.

A series of rigorous leak tests are performed on all of the piping installed in this equipment to ensure piping integrity. Because this equipment may be shipped with factory supplied external riser piping, it is necessary for the receiving inspector to carefully inspect this piping for signs of shipping damage. If damage is present, a claim must be filed with the freight carrier.

At the time of receipt, the equipment type and arrangement should be verified against the order documents. Should any discrepancy be found, the local Sales Representative should be notified immediately so that the proper action may be instituted. Should any question arise concerning warranty repairs, the factory must be notified BEFORE any corrective action is taken. Where local repairs or alterations can be accomplished, the factory must be fully informed as to the extent and expected cost of those repairs before work is begun. Where factory operations are required, the factory must be contacted for authorization to return equipment and a Return Authorization Number will be issued. Unauthorized return shipments of equipment and shipments not marked with an authorization number will be refused. In addition, the manufacturer will not accept any claims for unauthorized expenses.

### SHIP LOOSE ITEMS

Several components are shipped loose for field installation. These may include: thermostat, return air access panel, return air access panel fasteners, discharge grille(s), risers (optional). These parts are shipped loose to offer protection against shipping and job-site damage. Refer to packing slip.

## HANDLING & INSTALLATION

While all equipment is designed and fabricated of sturdy construction and may present a rugged appearance, great care must be taken to assure that no force or pressure be applied to the coil, risers, piping or drain stub-outs during handling. Do not use the risers for lifting the unit. Also, depending on the options and accessories, some units could contain delicate components that may be damaged by improper handling. Wherever possible, all units should be maintained in an upright position and handled by the exterior casing, with no impact forces applied that may damage internal components or painted surfaces.

The equipment covered in this manual IS NOT suitable for outdoor installations. The equipment should never be stored or installed where it may be subjected to a hostile environment such as rain, snow, extreme temperatures, or hazardous chemicals.

During and after installation, special care must be taken to prevent foreign material such as paint, plaster, and drywall dust from being deposited in the drain pan, electric heater, motor and blower wheels. Failure to do so may have serious adverse effects on unit operation and in the case of the heater, motor and blower assembly, may result in immediate or premature failure. All manufacturers' warranties are void if foreign material is allowed to be deposited on the heater, motor or blower wheels of any unit. Some units and/or job conditions may require some form of temporary covering during construction.

Condensate pan is internally sloped toward drain connection. Make assurance that unit is level and plumb. Level the unit to insure proper coil operation and condensate drainage. After units are positioned and risers centered in pipe chase, plumb the unit in two directions, using unit casing as a reference. Avoid any interference with wiring, coil, or coil connections, drain pan, and structural components inside the cabinet while using bolts or lag screws to anchor the unit to building. See *Figure 10 on page 16* for critical penetration areas.

After mounting the unit, it is then ready for the various service connections such as water, drain and electrical. At this time it should be verified that the proper types of service are actually provided to the unit. On those units requiring chilled water and/or hot water, the proper line size and water temperature should be available to the unit. The electrical service to the unit should be compared to the unit nameplate to verify

compatibility. The routing and sizing of all piping, and the type and sizing of all wiring and other electrical components such as circuit breakers, disconnect switches, etc. should be determined by the individual job requirements and should not be based on the size and/or type of connection provided on the equipment. All installations should be made in compliance with all governing codes and ordinances. Compliance with all codes is the responsibility of the installing contractor.

Any new field connections must ensure all openings are sealed and properly insulated. Improper sealing or insulation can result in untreated air infiltrating the unit. Units are not internally thermally isolated, proper thermal breaks required at installation to prevent adverse effects.



***For seismic certified installation, reference the seismic installation document.***

## COOLING/HEATING MEDIUM CONNECTIONS




***Toxic residues and loose particles resulting from manufacturing and field piping techniques such as joint compounds, soldering flux, and metal shavings may be present in the unit and the piping system. Special consideration must be given to system cleanliness when connecting to solar, domestic or potable water systems.***

Submittals and Product Catalogs detailing unit operation, controls, and connections should be thoroughly reviewed BEFORE beginning the connection of the various cooling and/or heating mediums to the unit.


All accessory valve packages should be installed as required, and all service valves should be checked for proper operation.

If coil and valve package connections are made with "sweat" or solder joint, care should be taken to assure that no components in the valve package are subjected to a high temperature which may damage seals or other materials. Many two-position electric control valves, depending on valve operation, are provided with a manual-opening lever. This lever should be placed in the "open" position during all soldering or brazing operations. Solder joints with Sil-fos®, phos-copper, or similar high temperature alloy. Do not use soft solder.



LD13870

FIGURE 1 - FLEX HOSE CONNECTIONS



NOTE:  
Valve package isolation valve shown, typical for riser shut off valve.

TO REGULATE FLOW (FIG. 2C):  
STEP 1. SET VALVE TO DESIRED FLOW.  
STEP 2. LOOSEN SCREW AT THE TOP OF VALVE.  
STEP 3. TURN MEMORY STOP TO "EAR" ON VALVE BODY.  
STEP 4. TIGHTEN SCREW AT TOP OF VALVE.

LD13871

FIGURE 2 - BALL VALVE WITH MEMORY STOP

## FLEX HOSE

All Vertical Hi-Rise and Tandem Master & Tandem Slave units use Kevlar reinforced braided stainless steel flexible hoses for all water piping between the coil and the risers or field piping. This factory piping includes two ball valves per coil, with memory stop. These hoses are designed with swivel connections on both ends, and require either a gasket or O-ring for positive sealing. See *Figure 1 on page 10* for connection details.

These hoses are designed to provide for riser movement due to thermal expansion, and allow for quick, easy coil removal through the use of the swivel connections.

During transit, vibration may cause a connection to loosen. Therefore, all threaded connections must be checked during unit installation. Any fitting that is loose must be tightened. The stationary side of any swivel connection must be prevented from twisting during tightening by the use of a “backup” wrench. Pressure test all joints before applying water.



*Some hose-to-coil joints are furnished with a removable vulcanized fiber gasket. This gasket (Part No. PH-05-0047) must be replaced each time the joint is broken. Later model units have a hose-to-coil joint with a black EDPM gasket (Part No. PH-05-0048). This gasket is re-useable, but may be replaced should it become damaged and no longer seal.*

## FACTORY INSTALLED RISERS

Units provided with factory installed water and drain risers include fully insulated risers as specified per order. The flex hose and ball valve described above is assembled to the riser and pressure tested at the factory. Each unit is configured for a specific location in the building, and is marked with that location by room number, floor, riser number, or other identification as specified per order.


Units provided with factory installed drain risers are supplied with “full height” drain risers that extend 3” above the top of the unit, and include the standard “swaged” section at the top. Field piping and venting of the drain riser must be furnished and installed by others.

Factory installed risers are strapped to the unit for shipment to prevent damage during transit. These shipping straps must be removed at installation to allow movement of the risers to assure proper alignment.

See *Figure 3 on page 11* and *Figure 4 on page 12* for details.




***At no time should a unit be lifted, moved, or otherwise handled by the risers.***




LD13872

**FIGURE 3 - FACTORY INSTALLED RISERS**



LD13873

**FIGURE 4 - FACTORY INSTALLED RISERS, MASTER/SLAVE CONFIGURATION**



LD13866


**FIGURE 5 - FACTORY FURNISHED, FIELD INSTALLED RISERS**

**FACTORY FURNISHED, FIELD INSTALLED RISERS**

Units provided with factory furnished, field installed water and drain risers include fully insulated risers as specified per order, which are shipped separately for installation on the job prior to receipt of the units. The ball valve previously described is assembled to the riser and pressure tested at the factory. The risers are packaged as a “kit” for a specific location in the building, and each “kit” is marked with that location by room number, floor, riser number, or other identification as specified per order.

Riser “kits” that include drain risers are supplied with “full height” drain risers that extend 3” above the top of the unit, and include the standard “swaged” section at the top, similar to factory installed riser sets. Field piping and venting of the drain riser must be furnished and installed by others.

See Figure 5 on page 12 for details.



LD13867

**FIGURE 6 - FACTORY FURNISHED, FIELD INSTALLED RISERS, MASTER/SLAVE**



*Field installed risers MUST be installed with the proper unit connection height and orientation to allow for correct unit installation at a later date. Swage is always oriented up. Refer to unit dimensional drawings.*

## FIELD FURNISHED AND INSTALLED PIPING OR RISERS

Units provided for field furnished and installed water and drain piping or risers include the flex hose and ball valve assemblies previously described. These hose and valve assemblies include a stub of copper tube for field connection to the unit piping. The factory hose and valve assemblies are marked by connection type and retracted inside the unit for shipment. Do not braze the pipe stub without opening the ball valve and disconnecting the hose. Riser stub out should slope down slightly away from the riser. This prevents condensation from dripping at the bottom of a riser column.

See *Figure 7 on page 13* for details.




**Field fabricated/installed piping and risers MUST be installed with the proper unit connection height and orientation to allow for correct unit installation at a later date. Refer to unit dimensional drawings.**

### RISER CONNECTION


Do not rigidly attach risers to this equipment. Risers must be free to move with thermal expansion and contraction. Units and risers are designed to accommodate a maximum of 3" (1-1/2" up and 1-1/2" down) total vertical movement. To achieve this range of movement, the risers must be installed according to the conditions outlined below. If the total combined riser expansion will exceed 3", additional expansion compensation, such as loops and expansion joints, or alternate riser anchoring techniques must be field furnished and installed.

Factory furnished risers are designed with a "swage" or socket in the top to accommodate 2" of tailpiece insertion from the riser above. The riser configuration, when combined with the required length as provided by the customer, is designed to position the riser-to-unit stub out piping at the vertical center of the riser slot in the unit casing. See unit submittal drawings for dimensional details. Due to building construction variations, some risers may require cutting or lengthening to correctly position the riser. Any field modifications are the responsibility of the installer.



LD13874

**FIGURE 7 - FIELD FURNISHED AND INSTALLED RISERS**



LD13875

**FIGURE 8 - FIELD FURNISHED AND INSTALLED RISERS MASTER/SLAVE**

After all connections are completed, and prior to insulating and furring-in of any riser or piping connections, the system should be tested for leaks. Since some components are not designed to hold pressure with a gas, hydronic systems should be tested with clear water. Care should be taken to completely drain the system, or otherwise protect it from freezing in cold weather.



***Standard unit operating pressure is 300 psig maximum. Field test pressure must not exceed 400 psig maximum. Some optional or special unit piping components may have lower pressure ratings than the standard unit. All valve and piping component pressure ratings must be verified before applying test pressure to the unit.***



***All water coils and unit piping must be protected from freezing after initial filling with water. Unit coils and piping may still hold enough water to cause damage when exposed to freezing temperatures, even after the system is drained.***

In the event that leaking or defective components are discovered, the Sales Representative must be notified BEFORE any repairs are attempted. All leaks should be repaired before proceeding with installation.

After all risers and piping are installed and pressure tested, all riser joints must have the insulation joint sealed and all other piping must be insulated in compliance with the project specifications. All chilled water risers, piping, and valves must be insulated or located over a drain pan, to prevent damage from condensation. This includes factory and field piping inside the unit cabinet.

The drain should always be connected and piped to an acceptable disposal point. For proper moisture carry-off, the drain piping should be sloped away from the unit at least 1/8" per foot. A drain trap is integral to the unit and is necessary for odor containment. The drain riser and piping must be installed to avoid pinching or kinking the unit drain tube.

Any required piping or riser penetration fire blocking is the responsibility of the installer. All penetrations for piping and risers should be sealed with materials and techniques suitable for all governing codes and ordinances.

## DUCTWORK CONNECTIONS

All ductwork and/or supply and return grills should be installed in accordance with the project plans and specifications. If not included on the unit or furnished from the factory, supply and return grilles should be provided as recommend in the product catalog.

All units must be installed in non-hazardous areas. Zero clearance to combustible materials is allowed.

Units provided with outside air for ventilation should have some form of low temperature protection to prevent coil freeze-up. This protection may be any of several methods such as a low temperature thermostat to close the outside air damper or a preheat coil to temper the outside air before it reaches the unit. It is recommended that outside air is pretreated to regulate its temperature and humidity ratio

It should be noted that none of these methods would adequately protect a coil in the event of power failure. The safest method of freeze protection is to use glycol in the proper percent solution for the coldest expected air temperature.

Flexible duct connections should be used on all air handling equipment. All ductwork and insulation should be installed to allow proper access to all components for service and repair such as filters motor/blower assemblies, etc.

## Dual Air Discharge Units

All dual discharge units are provided with a sight and sound baffle in the discharge plenum area (except top discharge units). It is recommended that a discharge grille with a damper be provided in one of the discharge locations to aid in air balancing. Dual discharge units with top discharge must be provided with a field supplied damper in the top discharge duct.




***Do not inhibit inlet or outlet connections. Quickly turning off the inlet or rapid reduction in ductwork can cause system effects that impact airflow. Reductions in airflow can cause electric heaters to overheat, condensation to form, or other unintended consequences, which can result in injury, property damage, equipment damage, as well as void factory warranty.***

## FIELD RECONFIGURABLE RISERS AND DISCHARGE OPENINGS

### Riser Reconfiguration

Vertical Hi-Rise units are furnished with riser slot “knockouts” in the casing back and both sides. Should it be necessary to relocate risers in the field, the water risers may be disconnected at the swivel joint on the riser isolation valve, and removed from the unit. The drain riser may be removed by moving the drain tube hose clamp and removing the riser tube from the drain hose.

The water riser slot “knockouts” may be removed by clipping the “tabs” to separate the inner portion of the knockout. See *Figure 9 on page 15* for details. After opening the riser slot, make a vertical slit in the cabinet insulation with a sharp utility knife. This slit must be centered left to right, and full height in the slot. The water riser may now be re-installed at the desired location by inserting the valve through the new opening. Insert the valve through the opening with care to avoid damage to the cabinet insulation. Make sure that the swivel joint O-ring is undamaged, and re-attach the hose to the valve with the O-ring in place. Replacement O-rings (Part No. PR-07-0115) may be ordered through the parts department.



LD13876

**FIGURE 9 - KNOCKOUT REMOVAL**

After relocating all the risers, pressure test the joints to assure system integrity.

The drain riser slot is already present on the back, left and right sides. To install the drain riser, insert the riser tube into the unit and connect the drain hose using the hose clamp preciously removed.

After all the risers have been relocated, inspect the cabinet insulation where the risers were removed, and repair any insulation damage before starting the unit and cover unused openings.

### DISCHARGE OPENING RECONFIGURATION

Vertical Hi-Rise and Tandem Master & Tandem Slave units are furnished with discharge opening “knockouts” in all four sides and the top. Should it be necessary to reconfigure a unit for a different discharge arrangement than originally provided, the new discharge opening may be created by clipping the tabs of the desired opening to remove the inner portion of the “knockout”. The side flanges may then be folded out to provide the drywall stops for the opening. See *Figure 9 on page 15* for details.

After the new opening is created, the cabinet insulation must be trimmed out, and the edges of the insulation should be coated with duct board adhesive or appropriate liner tape to prevent erosion into the airstream.


Any unused discharge openings must have the drywall stops bent back flush with the unit casing. The opening must then be covered with an insulated plate. Any cover plates and insulation must be provided and installed by others.

Relocating a discharge opening on a double discharge unit may require removal or relocation of any factory provided sight and sound baffle. Consult the factory for details on requirements and relocation of sight and sound baffles.



***Size 10 and 12 units factory furnished with double discharge do not have discharge “knockouts” to allow field conversion to a single discharge. Consult the factory for details.***

The manufacturer assumes no responsibility for undesirable system operation due to improper field design, equipment or component selection, and/or installation of ductwork, grilles, and other related components.



**FIGURE 10 - CRITICAL PENETRATION AREAS**

### WALL FRAMING

All wall framing is the responsibility of others. The Vertical Hi-Rise and Tandem Master & Tandem Slave unit casing is designed to be concealed by a finished wall or enclosure that is installed in the field by others. This enclosure may be a framed structure with gypsum board or other material covering as selected by others. Where desired, the gypsum board or paneling may be applied directly to the unit casing. If the direct application method is used, care must be taken when installing the fasteners so as not to damage any internal components. See *Figure 10 on page 16* for critical penetration areas.

Due to factory manufacturing tolerances and jobsite construction variations, some unit casing surface conditions may exist that could require additional framing or shimming of the finished wall surface. **ALL WORK REQUIRED TO ACHIEVE THE DESIRED FINISHED WALL SURFACE CONDITION IS THE RESPONSIBILITY OF OTHERS.**

1. Attaching fasteners should be no longer than necessary to provide proper grip.
2. Do not locate fasteners where they could penetrate coils, risers, piping, electrical enclosures or other components.
3. Do not locate fasteners where they would pose a safety hazard during access or service on any internal components.
4. Do not locate fasteners where they would impede the access or removal of any internal component.
5. Verify that all enclosure attachment points are located properly and do not pose any safety hazards or damage any internal components before bringing the enclosure surface to finished condition (e.g., finish drywall or apply wall covering).


### TANDEM MASTER & TANDEM SLAVE UNIT INSTALLATION

(See *SECTION 6 - Dimensional Data* for details)

Tandem Master & Tandem Slave units are shipped as a factory assembled pair and are intended for installation with the space separating the units to be included in the wall between the units. Tandem Master & Tandem Slave units are available with fire rated and non-fire rated construction.

Non-fire rated unit pairs may be installed as required to achieve the finished wall configuration desired. Wall framing and drywall application should be accomplished as noted above.

Fire rated unit pairs are designed to be installed with the space between the units becoming part of a fire rated wall usually used to separate specific occupancies. These unit pairs must be installed according to the procedure shown on Tandem Master & Tandem Slave Installation Instructions to maintain the fire rating for the unit.



**FIGURE 11 - OUTSIDE AIR CONNECTION**

### OUTSIDE AIR CONNECTION

The optional 6" diameter round outside air connection is provided with either a round butterfly manual damper, or a rectangular motorized damper assembly, for outside air control. See *Figure 11 on page 17* for details. Installation of outside air duct connections may require installation of a vapor barrier between the unit and the wall, and may require freeze protection control devices. These components must be supplied and installed by others as required. It is recommended that all outside air be pretreated to regulate its temperature and humidity ratio.

### MANUAL OUTSIDE AIR DAMPER

The manual outside air damper may be adjusted by loosening the wing nuts on the top and bottom, and setting the adjustment lever to the required position for the desired amount of outside air. The wing nuts are then tightened to lock the damper in place.

### MOTORIZED OUTSIDE AIR DAMPER

The standard motorized outside air damper is factory wired to open the damper when the fan is operating. Other damper operating sequences are available. See individual order documents to verify actual damper operation.

The motorized outside air damper is factory set to drive from full closed to full open. The damper may be adjusted in the field to set the desired amount of outside air by the following steps:

1. Loosen the set screw in the damper actuator set collar and turn on all power and set all controls to call for full outside air. This should drive the damper actuator to the "full open" position.
2. Manually position the damper blade to achieve the desired amount of outside air.
3. Tighten the set screw to lock the damper blade to the actuator set collar.
4. Disconnect power or set controls to de-energize the outside air, and verify that the damper drives to the "closed" position.
5. Re-energize the outside air and verify that the damper returns to the position set in Step 2.

### ELECTRICAL CONNECTIONS SHOCK / ELECTRICAL HAZARDS

The unit nameplate lists the unit electrical characteristics such as the required supply voltage, fan and heater amperage, unit minimum circuit ampacity, and maximum overcurrent protective device. The unit-wiring diagram shows all unit and field wiring. Since each project is different and each unit on a project may be different, the installer must be familiar with the wiring diagram and nameplate on the unit **BEFORE** beginning any wiring. Provide for adequately sized fuse, circuit breaker or disconnect means as applicable to meet local and national electrical codes. All electrical connections should be checked for tightness prior to startup.

All components furnished for field installation, by either the factory or the controls contractor should be located and checked for proper function and compatibility. All internal components should be checked for shipping damage and any loose connections should be tightened to minimize problems during startup.

Any devices such as fan speed switches or thermostats that have been furnished from the factory for field installation must be wired in strict accordance with the applicable wiring diagrams. Failure to do so could result in personal injury or damage to components and will void all manufacturers' warranties. Refer to the diagram within unit.

## **THERMOSTATS**

Various types of thermostats are available for this unit. Unit surface mounted thermostats are provided with a drywall mud ring for field mounting. The mud ring may be located on the unit front or either side as appropriate in the field. For remote mounted thermostats, the mud ring should be removed from the unit and re-installed on the thermostat mounting box, or discarded as necessary. Unit surface mounted thermostats are provided with a plug assembly for easy connection.

The plug is polarity specific and connects only in one direction. Remote thermostats must be field wired to unit's connection points as indicated on the unit's wiring diagram.

The fan motor(s) should never be controlled by any wiring or device other than the factory furnished switch or thermostat/switch combination, without factory authorization.

All field wiring should be done in accordance with governing codes and ordinances. Any modification of the unit wiring without factory authorization will result in voiding of all factory warranties and will nullify any agency listings.

The manufacturer assumes no responsibility for any damages and/or injuries resulting from improperly field installed or wired components.

## SECTION 2 - START-UP

### GENERAL

Before beginning any start-up operation, the start-up personnel should familiarize themselves with the unit, options and accessories, and control sequence to understand the proper system operation. All personnel should have a good working knowledge of general start-up procedures and have the appropriate start-up and balancing guides available for consultation.

The building must be completely finished including doors, windows, and insulation. All internal walls and doors should be in place and in the normal position. In some cases the interior decorations, curtains and furniture may influence overall system performance by blocking return or supply air openings. The entire building should be as complete as possible before beginning any system balancing. Operation of the unit during construction is not recommended since construction dust will foul filters and coils and can seriously degrade unit performance.

The initial step in any start-up operation should be a final visual inspection. All equipment, duct-work, and piping should be inspected to verify that all systems are complete and properly installed and mounted and that no construction debris or foreign articles such as paper or drink cans are left in the units.



***Fan coils are not intended for temporary heat/cool or ventilation. Units are not designed or equipped to operate in dusty construction environments. Operation of the units in conditions outlined above could result in damage.***

Each unit should be checked for loose wires, free blower wheel operation, and loose or missing access panels or doors. Except as required during start-up and balancing operations, no fan coil units should be operated without all the proper duct-work attached, supply and return grills in place, and all access doors and pan-

els in place and secure. A clean filter of the proper size and type must also be installed. Failure to do so could result in damage to the equipment or building and furnishings, and/or void all manufacturers' warranties.

### COOLING/HEATING SYSTEM

Prior to the water system start-up and balancing, the chilled/hot water systems should be flushed to clean out dirt and debris, which may have collected in the piping during construction. During this procedure, all unit service valves must be in the closed position. This prevents foreign matter from entering the unit and clogging the valves and metering devices. Strainers should be installed in the piping mains to prevent this material from entering the units during normal operation.

During system filling, air venting from the unit is accomplished by the use of the standard manual, or optional automatic, air vent fitting installed on the coil. In the case of the manual air vent fitting, the screw should be turned counterclockwise no more than 1-½ turns to operate the air vent. Automatic air vents may be unscrewed one turn counterclockwise to speed initial venting but should be screwed in for automatic venting after start-up operations.



***The air vent provided on the unit is not intended to replace the main system air vents and may not release air trapped in other parts of the system. Inspect the entire system for potential air traps and vent those areas independently as required. In addition, some systems may require repeated venting over a period of time to properly eliminate air from the system.***



***Do not exceed 450 PSIG operating pressure.***

## AIR SYSTEM BALANCING

All ductwork must be complete and connected, and all grilles, filters, and access doors and panels must be properly installed to establish actual system operating conditions BEFORE beginning air balancing operations.

Each individual unit and associated ductwork is a unique system with its own operating characteristics. For this reason, air balancing is normally done by balance specialists who are familiar with all procedures required to properly establish air distribution and fan system operating conditions. These procedures should not be attempted by unqualified personnel.

After the proper system operation is established, the actual unit air delivery and the actual fan motor amperage draw for each unit should be recorded in a convenient place for future reference such as the inspection, installation, and start-up check sheet (see *SECTION 4 - INSPECTION, INSTALLATION & START-UP CHECKLIST*). Contact the Sales Representative or the factory for additional copies of this sheet.

## WATER SYSTEM BALANCING

A complete knowledge of the hydronic system, its components, and controls is essential to proper water system balancing and this procedure should not be attempted by unqualified personnel. The system must be complete and all components must be in operating condition BEFORE beginning water system balancing operations. All connections must be checked to ensure they are adequately tightened after shipment; components may loosen during shipment to job site.

Each hydronic system has different operating characteristics depending on the devices and controls in the system. The actual balancing technique may vary from one system to another.

After the proper system operation is established, the appropriate system operating conditions such as various water temperatures and flow rates should be recorded in a convenient place for future reference such as the inspection, installation, and start-up check sheet (see *SECTION 4 - INSPECTION, INSTALLATION & START-UP CHECKLIST*).

Before and during water system balancing, conditions may exist which can result in noticeable water noise or undesired valve operation due to incorrect system pressures. After the entire system is balanced, these conditions will not exist on properly designed systems. If unit is ordered with P.T. ports, these should be used to measure the pressure differential across the coil.

## CONTROLS OPERATION

Before proper control operation can be verified all other systems must be in proper operation. The correct water and air temperatures must be present for the control function being tested. Some controls and features are designed not to operate under certain conditions.

A wide range of controls and electrical options and accessories may be used with the equipment covered in this manual. Consult the approved unit submittals, order acknowledgement, and other manuals for detailed information regarding each individual unit and its controls. Since controls and features may vary from one unit to another, care should be taken to identify the controls to be used on each unit and their proper control sequence. Information provided by component manufacturers regarding installation, operation, and maintenance of their individual controls is available upon request.



***Fan coil units, which allow water flow through the coils while the fan is in the OFF position, can create condensation on the exterior of the cabinet.***

## SECTION 3 - NORMAL OPERATION & PERIODIC MAINTENANCE

### GENERAL

Each unit on a job will have its own unique operating environment and conditions that may dictate maintenance schedule for that unit that is different from other equipment on the job. A formal schedule of regular maintenance and an individual unit log should be established and maintained. This will help to achieve the maximum performance and service life of each unit on the job.

Information regarding safety precautions contained in the preface at the beginning of this manual should be followed during any service and maintenance operations.

For more detailed information concerning service operations, consult your Sales Representative or the Factory.

### MOTOR/BLOWER ASSEMBLY

The type of fan operation is determined by the control components and their method of wiring, and may vary from unit to unit. Refer to the wiring diagram for each unit for that unit's individual operating characteristics. All motors have internal automatic reset thermal overloads.

Should the assembly require more extensive service, the motor/blower assembly may be removed from the unit to facilitate such operations as motor or blower wheel/housing replacement, etc. The motor/blower assembly is supplied on a slide-out rail system (see *Figure 30 on page 21*). To remove, loosen the two lock nuts at the rack front and slide the blower assembly out. Disconnect the motor electrical plug to fully remove the assembly from the unit. To reinstall the blower, repeat the removal sequence in reverse order. The rear of the blower must catch on the support bracket supplied.

Dirt and dust should not be allowed to accumulate on the blower wheel or housing. This can result in an unbalanced blower wheel condition that can damage a blower wheel or motor. The wheel and housing may be cleaned periodically using a vacuum cleaner and a brush taking care not to dislodge the factory balancing weights on the blower wheel blades.




FIGURE 12 - MOTOR/BLOWER ASSEMBLY

### COIL

Coils may be cleaned by brushing the entering air face between fins with a soft brush. Brushing should be followed by cleaning with a vacuum cleaner. If a compressed air source is available, the coil may also be cleaned by blowing air through the coil fins from the leaving air face. Vacuuming should again follow this procedure. Units provided with the proper type of air filters, replaced regularly, will still require periodic coil cleaning.

### ELECTRIC RESISTANCE HEATER ASSEMBLY

Electric resistance heaters typically require no normal periodic maintenance when unit air filters are changed properly. The two most important operating conditions for an electric heater are proper airflow and proper supply voltage. High supply voltage and/or poorly distributed or insufficient airflow over the element will result in element overheating. This condition may result in the heater cycling on the high limit thermal cutout. Open coil strip heaters have an automatic reset switch with a back-up high limit thermal switch. Automatic reset switches are as the name implies; they reset automatically after the heater has cooled sufficiently. High limit thermal switches must be replaced once the circuit has been broken. The high limit thermal cutout device is a safety device only and is not intended for continuous operation. With proper unit application and operation, the high limit thermal cutout will not deactivate the heater. This device only operates when some problem exists and ANY condition that causes high limit cutout

MUST be corrected immediately. High supply voltage also causes excessive amperage draw and may result in tripping of the circuit breaker or blowing of the fuses on the incoming power supply.



**Window treatments and drapes must not be positioned in a manner which obstructs the air flow through the return air or discharge grilles.**


After proper air flow and supply power are assured, regular filter maintenance is important to provide clean air over the heater. Dirt that is allowed to deposit on the heating element will cause hot spots and eventual element burn-through. These hot spots will normally not be enough to trip the thermal high limit and may not be evident until actual heater element failure. Heaters may be serviced through the unit's electrical section (see *Figure 31* on page 22). To remove heater, disconnect unit power, remove heater connecting wiring and the element mounting screws.

## ELECTRICAL WIRING & CONTROLS

The electrical operation of each unit is determined by the components and wiring of the unit and may vary from unit to unit. Consult the wiring diagram for the actual type and number of controls provided on each unit.

The integrity of all electrical connections should be verified at least twice during the first year of operation. Afterwards, all controls should be inspected regularly for proper operation. Some components may experience erratic operation or failure due to age. Wall thermostats may also become clogged with dust and lint and should be periodically inspected and cleaned to provide reliable operation.

When replacing any components such as fuses, contactors, or relays, use only the exact type, size, and voltage component as furnished from the factory. Any deviation without factory authorization could result in personnel injury or damage to the unit and will void all factory warranties. All repair work should be done in such a manner as to maintain the equipment in compliance with governing codes and ordinances or testing agency listings. More specific information regarding the use and operating characteristics of the standard controls offered by this manufacturer is contained in other manuals.



**FIGURE 13 - ELECTRIC HEAT**

## VALVES & PIPING

With the exception of strainers, no formal maintenance is required on the valve package components most commonly used with fan coil units. During normal periodic maintenance, the valve packages may be visually inspected for possible leaks.

Valve packages with strainers should have the strainers cleaned after startup. The strainers may require cleaning several times immediately after startup until the system is thoroughly cleaned and stabilized. After that, a schedule should be determined for regular inspection of the strainers.

In the event that a valve or component should need replacement, the same precautions taken during the initial installation to protect the components from excessive heat should be observed during replacement.

## FILTERS, THROWAWAY

The type of throwaway filter most commonly used on fan coil units should be replaced on a regular basis. The time interval between each replacement should be established based on regular inspection of the filter and should be recorded in the log for each unit. Refer to the product catalog for the recommended filter size for each product type and size. If the replacement filters are not purchased from the factory, the filters used should be the same type and size as that furnished from or recommended by the factory. Consult the factory for applications using filter types other than the factory standard or optional product. Dirty filters are the cause of the most common system performance complaints. It is essential that filters be serviced on a regular basis.


## DRAIN

The drain should be checked before initial start-up and at the beginning of each cooling season to assure that the drain trap and line are clear. If it is clogged, steps should be taken to clear the debris so that condensate will flow easily.

Periodic checks of the drain should be made during the cooling season to maintain a free flowing condensate. Should the growth of algae and/or bacteria be a concern, consult an air conditioning and refrigeration supply organization familiar with local conditions for chemicals available to control these agents. The drain trap is a flexible rubber hose. It is secured to the drain pan and riser with clamps and is easily removable for service.

## OPTIONAL REMOVABLE DRAIN PAN

An optional removable drain pan is available for easy service and cleaning (see *Figure 32 on page 23*). To remove the pan, disconnect the drain p-trap by loosening the hose clamp under the pan. Remove the retainer plate at the front of the pan and slide the pan out of its track. Clean or service pan as appropriate. Reinstall pan in reverse sequence. Retainer plate must be installed for proper operation.



LD13880

**FIGURE 14 - DRAIN PAN REMOVAL**

## REPLACEMENT PARTS

Factory replacement parts should be used wherever possible to maintain the unit performance and operating characteristics and the testing agency listings. Replacement parts may be purchased through the local Sales Representative.

Contact the local Sales Representative or the factory before attempting any unit modifications. Any modifications not authorized by the factory could result in personnel injury and damage to the unit and could void all factory warranties.

When ordering parts, the following information must be supplied to ensure proper part identification:

1. Complete unit model number.
2. Unit hand connection (right or left hand) while facing into the air stream.
3. Complete part description including any numbers.

On warranty replacements, in addition to the information previously listed, the Factory Order Number (CO#) that appears on the unit nameplate, is required. Contact the factory for authorization to return any parts such as defective parts replaced in warranty. All shipments returned to the factory **MUST** be marked with a Return Authorization Number, which is provided by the factory.

All equipment and components sold through the Parts Department are warranted under the same conditions as the standard manufacturers' warranty with the exception that the warranty period is 12 months unless the component is furnished as warranty replacement. Parts furnished as warranty replacements are warranted for the remaining term of the original unit warranties.

## SECTION 4 - INSPECTION, INSTALLATION & START-UP CHECKLIST

**RECEIVING & INSPECTION**

**DATE:**

**BY:**

- Unit Received Undamaged
- Unit Received Complete As Ordered
- Unit Arrangement Correct
- Unit Structural Support Complete & Correct


**HANDLING & INSTALLATION**

- Unit Mounted Level & Square
- Proper Access Provided For Unit & Accessories
- Proper Electrical Service Provided
- Proper Overcurrent Protection Provided
- Proper Service Switch/Disconnect Provided
- Proper Chilled Water Line Size To Unit
- Proper Hot Water Line To Unit
- All Services To Unit In Code Compliance
- All Shipping Screws & Braces Removed


**COOLING/HEATING CONNECTIONS**

- Protect Valve Package Components From Heat
- Mount Valve Packages
- Connect Field Piping To Unit
- Pressure Test All Piping For Leaks
- Install Drain Line & Traps As Required
- Insulate All Piping As Required


**DUCTWORK CONNECTIONS**

- Install Ductwork, Fittings & Grilles As Required
- Proper Supply & Return Grille Type & Size Used
- Control Outside Air For Freeze Protection
- Insulate All Ductwork As Required


**ELECTRICAL CONNECTIONS**

- Refer To Unit Wiring Diagram
- Connect Incoming Power Service or Services
- Electrical Service of Correct Voltage and Ampacity to Support Unit Operating Loads
- All Field Wiring Installed With Code Compliance
- Check All Wiring For Secure Connections


**UNIT START-UP**

**DATE:**

**BY:**

- General Visual Unit & System Inspection \_\_\_\_\_
- Record Electrical Supply Voltage \_\_\_\_\_
- Record Ambient Temperature \_\_\_\_\_
- Close All Unit Isolation Valves \_\_\_\_\_
- Flush Water Systems \_\_\_\_\_
- Fill Systems With Water/Refrigerant \_\_\_\_\_
- Vent Water Systems As Required \_\_\_\_\_
- All Ductwork & Grilles In Place \_\_\_\_\_
- All Unit Panels & Filters In Place \_\_\_\_\_
- Start Fans, Etc. \_\_\_\_\_
- Check For Overload Condition Of All Units \_\_\_\_\_
- Check All Ductwork & Units For Air Leaks \_\_\_\_\_
- Balance Air Systems As Required \_\_\_\_\_
- Record All Final Settings For Future Use \_\_\_\_\_
- Check Piping & Ductwork For Vibration \_\_\_\_\_
- Check All Dampers For Proper Operation \_\_\_\_\_
- Verify Proper Cooling Operation \_\_\_\_\_
- Verify Proper Heating Operation \_\_\_\_\_
- Reinstall All Covers & Access Panels \_\_\_\_\_

**SERVICE INTERVALS (record dates service performed):**

Filters: \_\_\_\_\_

Drain Pan: \_\_\_\_\_

Motor/Blower: \_\_\_\_\_

Coil: \_\_\_\_\_

Controls: \_\_\_\_\_

General: \_\_\_\_\_

## SECTION 5 - TROUBLESHOOTING


SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
<b>NO UNIT OPERATION</b>	No power to unit.	Apply proper power to unit.
	Improper power to unit.	Apply proper power to unit and check for damaged components and/or blown fuses, if furnished.
	Power distribution panel switch or circuit breaker in "OFF" position.	Turn power distribution panel switch or circuit breaker to "ON" position.
	Unit toggle or door interlock disconnect switch in "OFF" position.	Turn unit toggle or door interlock disconnect switch to "ON" position.
	Fan switch or thermostat system switch in "OFF" position.	Turn fan switch or thermostat system switch to "ON" position.
	Blown or defective unit main fuse, if furnished.	Check for possible defective component or improper wiring, and replace fuse.
	Blown or defective fan motor fuse, if furnished.	Check for possible defective component or improper wiring, and replace fuse.
	Defective toggle, door interlock, fan, or thermostat system switch.	Momentarily jumper suspected component to simulate closed contacts and achieve unit operation. Replace defective device with known good part.
	Loose or improper wiring from power distribution and/or remote mounted control devices.	Verify all wiring connections and terminations, and verify proper wiring of all incoming power devices and remote mounted controls.
<b>UNIT BLOWS MAIN UNIT OR FAN MOTOR FUSE WHEN POWER IS APPLIED TO UNIT</b>	Defective or improperly wired component.	Using a battery powered continuity tester, check for shorted or grounded components starting at incoming power. Note position of all controls during various component checks. Caution: some voltages have isolated common which may not show a short to chassis ground. Be sure to isolate each control to eliminate faulty reading through a parallel wired component.
<b>FAN DOES NOT RUN WITH POWER TO UNIT</b>	Fan switch in "OFF" position.	Turn fan switch to "ON" position.
	Thermostat system switch in "OFF" position.	Turn thermostat system switch to "ON" position.
	Remote "start/stop" switch in "OFF" position.	Turn remote "start/stop" switch to "ON" position.
	Loose or improper wiring from fan switch or thermostat to unit.	Verify all wiring connections and terminations, and verify proper wiring of all control devices.
	Loose or improper wiring from remote "start/stop" switch to unit "start/stop" relay.	Verify all wiring connections and terminations, and verify proper wiring of remote "start/stop" switch.
	Defective fan switch.	Momentarily jumper fan switch to each fan speed wire to simulate proper fan switch operation. Replace defective fan switch.
	Defective "start/stop" relay.	Momentarily jumper "start/stop" relay to simulate proper relay operation. Replace defective "start/stop" relay.
	Defective fan motor.	Verify proper fan switch operation and replace defective fan motor.

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
<b>FAN MOTOR HUMS AND/OR GETS HOT, BUT RUNS AT REDUCED SPEED OR NOT AT ALL</b>	Improper power applied to unit.	Apply proper power to unit.
	Defective motor capacitor.	Replace with known good capacitor.
	Defective fan motor.	Replace defective motor.
	Blower wheel jammed in housing.	Reposition blower wheel for proper alignment in housing, or replace if damaged.
	Foreign object in blower wheel.	Remove foreign object and replace blower wheel if damaged.
<b>FAN RUNS BUT VIBRATES</b>	Blower wheel dirty.	Remove and clean blower wheel taking care not to remove or reposition balance weights.
	Blower wheel bent.	Replace blower wheel.
	Blower wheel out of balance.	Replace blower wheel.
	Foreign object in blower wheel.	Remove foreign object and replace blower wheel if damaged.
	Loose motor mount screws.	Verify proper motor and blower wheel position and tighten motor mount screws. Do not crush mounting grommets.
	Broken motor mount frame or mounting screws.	Replace motor or mounting screws.
<b>FAN RUNS BUT BLOWER WHEEL RUBS HOUSING</b>	Bent blower wheel.	Replace blower wheel.
	Blower wheel not positioned properly on motor shaft.	Check for damage to blower wheel. Reposition blower wheel on motor shaft or replace as required.
<b>FAN RUNS BUT AIR DELIVERY IS LOW</b>	Incorrect fan speed has been selected.	Reselect proper fan speed as required.
	Dirty air filter.	Replace air filter.
	Dirty coil.	Clean coil.
	Obstruction in ductwork.	Check for improperly positioned balancing or fire dampers. Check for fallen duct liner. Repair as required.
	Actual E.S.P. higher than design.	Check installation for proper supply and/or return grilles, and compliance with plans and specifications.
<b>FAN RUNS BUT NO COOLING/ HEATING. (HYDRONIC UNITS)</b>	No chilled/hot water flow in system.	Establish chilled/hot water flow in system as required.
	Unit isolation valves closed.	Open unit isolation valves.
	Debris in water piping blocking flow.	Locate and clear debris from water piping as required.
	Plugged strainer on units so equipped.	Clean or remove strainer screen as required.
	Riser or main flushing loop open.	Close flushing loop valve as required.
	Loose or improper wiring from thermostat to control valve.	Verify all wiring connections and terminations, and verify proper wiring of thermostat.
	Defective thermostat.	Momentarily jumper thermostat contacts to simulate proper operation. Replace thermostat as required.
	Defective control valve actuator.	Manually place control valve in "open" position using lever on actuator housing. Replace actuator as required.
	Improper aquastat operation on units so equipped.	Verify proper aquastat position and operation. Replace as required.

SYMPTOM	POSSIBLE CAUSE	CORRECTIVE ACTION
<b>FAN RUNS BUT NO HEATING. (ELECTRIC HEAT UNITS)</b>	No power to electric heat circuit on units with dual point power.	Establish power to electric heat circuit.
	Loose or improper wiring from thermostat to electric heat contactor.	Verify all wiring connections and terminations, and verify proper wiring of thermostat.
	Loose or improper wiring of electric heat element.	Verify all wiring connections and terminations, and verify proper wiring of electric heat element.
	Defective electric heat contactor.	With electric heat contactor energized, verify proper voltage on contactor load terminals. Replace as required.
	Tripped or defective primary high limit switch.	Turn thermostat to lowest set point and allow fan to run 10-15 minutes for limit switch to cool and reset. Then turn thermostat to highest set point and check for proper heating operation. If high limit trips again, check for the following conditions: improper voltage to heater element; obstructed fan or unit outlet reducing air flow over heater element; dirty or defective heater element causing hot spot. If heater does not operate after sufficient time for limit switch to cool, disconnect power and check continuity across primary high limit switch. Replace if defective.
	Tripped secondary high limit switch.	Secondary high limit switches are designed to trip only during extreme failure conditions. Contact factory before attempting any corrective action.
	Defective thermostat.	Momentarily jumper thermostat contacts to simulate proper operation. Replace thermostat as required.
	Defective electric heat element.	Disconnect power and check continuity through heat element. Replace as required.
Improper aquastat or change over relay operation on units so equipped. (Note: electric heat will not operate when hot water is present at the unit.)	Verify proper aquastat position on piping, and verify proper aquastat and change over relay operation. Replace as required.	

## SECTION 6 - DIMENSIONAL DATA


The drawings in this section are for reference only and should not be used for construction purposes. Reference submittal documents for most current version.



**NOTES:**

1. All dimensions are Inches [mm]. Metric values are soft conversion.
2. All dimensions are ±1/4 [6mm].
3. Tile ring is installed on front of unit as shown, and may be moved to left or right side of unit in field. Tile ring is omitted on units with "ADA" control mounting location.
4. Wiring from electrical entry point to control enclosure is furnished and installed by others in field.
5. Risers available from 3/4" [19mm] to 3" [76mm] diameter with 1/2" [13mm] thick insulation, and 3/4" [19mm] to 2-1/2" [64mm] diameter with 3/4" [19mm] thick insulation.
6. All piping and insulation between master and slave units is furnished and installed in the field by others.
7. Riser length is 120" [3048mm] max, 100" [2540mm] min.
8. Back riser location shown. See arrangement drawings for available unit configurations.
9. Slave unit stubout dimension is approximate and varies with riser diameter. Stubout extends approximately 4" from riser tube.
10. Water piping connections are 5/8" [16mm] O.D. and drain connection is 7/8" [22mm] O.D.
11. Factory mounted risers shown. Risers may be shipped separately.

**FIGURE 15 - MODEL VHM, VERTICAL CONCEALED MASTER HIGH RISE, FCU, 88" CABINET**




**DIMENSIONS - In [mm]**

UNIT SIZE	A	B	SINGLE SUPPLY		E
			C	D	
03 & 04	18 [457]	16-1/2 [419]	16 [406]	8 [203]	6 [152]
06 & 08	20 [508]	18-1/2 [470]	18 [457]	12 [305]	6 [152]
10 & 12	24 [610]	22-1/2 [572]	22 [559]	14 [356]	8 [203]

**NOTES:**

- All dimensions are Inches [mm]. Metric values are soft conversion.
- All dimensions are ±1/4 [6mm].
- Tile ring is installed on front of unit as shown, and may be moved to left or right side of unit in field. Tile ring omitted on units with "ADA" control mounting location.
- Wiring from electrical entry point to control enclosure is furnished and installed in the field by others.
- All piping and insulation between slave unit and risers is furnished and installed in the field by others.
- Back connection location shown. See arrangement drawings for available unit configurations.
- All coil and drain connections are "retracted" and braced internally for shipment.
- Coil connections are 5/8" [16mm] O.D. female sweat. Drain "P-trap" is designed to accept 7/8" [22mm] O.D. copper tube.
- Slave units are furnished with factory installed shutoff valves and field connection tubes, unless master unit risers are shipped loose. Risers may be shipped separately.

**FIGURE 16 - MODEL VHS, VERTICAL CONCEALED SLAVE HIGH RISE, FCU, 88" CABINET**




NOTES:

1. All dimensions are Inches [mm]. Metric values are soft conversion.
2. All dimensions are ±1/4 [6mm].
3. Thermostat mounting- Tile ring is installed on front of unit as shown and may be moved to left or right side of unit in field. Tile ring is omitted on units with "ADA" control mounting location.
4. Wiring from electrical entry point to control enclosure is furnished and installed by others in field.
5. Risers available from 3/4" [19mm] to 2-1/2" [64mm] diameter with 1/2" [13mm] or 3/4" [19mm] thick insulation.
6. Riser length is 120" [3048mm] max, 100" [2540mm] min.
7. NON-FIRE RATED unit shown with type-X gypsum board at back of slave unit. FIRE RATED units have type-X gypsum board at back of both slave and master units. FIRE RATED unit design has been tested in accordance with UL1479 - Fire Tests Of Through Penetration Fire Stops, and is approved to bear the ETL listing mark for Through Penetration Fire Stop Assemblies.
8. For further fire rating information refer to the Installation Instructions, drawing 70-74-023
9. See page 2 of 2 for dimensions.
10. Refer to VH Enviro-Pac™ unit configuration drawing for additional unit configurations.

**FIGURE 17 - MODEL VHA/VHB, VERTICAL HI-RISE TANDEM FIRE RATED AND NON-FIRE RATED, FCU COMBINATIONS, 88" CABINETS**

<b>DIMENSIONS - In [mm]</b>						VHA/VHB SUPPLY AIR		
VHA (MASTER)	VHB (SLAVE)	A	B	C	D	SINGLE/ DOUBLE	TOP	
						E	F	G
03 or 04	03 or 04	18 [457]	42-1/4 [1073]	16-1/2 [419]	16 [406]	8 [203]	6 [152]	8 [203]
03 or 04	06 or 08	20 [508]	46-1/4 [1175]	18-1/2 [470]	18 [457]	12 [305]	6 [152]	12 [305]
03 or 04	10 or 12	24 [610]	54-1/4 [1378]	22-1/2 [572]	22 [559]	14 [356]	8 [203]	14 [356]
06 or 08	03 or 04	20 [508]	46-1/4 [1175]	18-1/2 [470]	18 [457]	12 [305]	6 [152]	12 [305]
06 or 08	06 or 08							
06 or 08	10 or 12	24 [610]	54-1/4 [1378]	22-1/2 [572]	22 [559]	14 [356]	8 [203]	14 [356]
10 or 12	03 or 04	24 [610]	54-1/4 [1378]	22-1/2 [572]	22 [559]	14 [356]	8 [203]	14 [356]
10 or 12	06 or 08							
10 or 12	10 or 12							



6

**DIMENSIONS - In [mm]**


UNIT SIZE	A	B	C	SINGLE SUPPLY		DOUBLE SUPPLY		TOP SUPPLY		F
				D	E	D	E	D	E	
03 & 04	18 [457]	23-3/8 [594]	16-1/2 [419]	16 [406]	8 [203]	16 [406]	8 [203]	16 [406]	8 [203]	6 [152]
06 & 08	20 [508]	25-3/8 [645]	18-1/2 [470]	18 [457]	8 [203]	18 [457]	8 [203]	18 [457]	12 [305]	6 [152]
10 & 12	24 [610]	29-3/8 [746]	22-1/2 [572]	-- [--]	-- [--]	22 [559]	8 [203]	22 [559]	12 [305]	8 [203]

**NOTES:**

- All dimensions are Inches [mm]. Metric values are soft conversion.
- All dimensions are ±1/4 [6mm].
- Tile ring is installed on front of unit as shown, and may be moved to left or right side of unit in field.
- Wiring from electrical entry point to control enclosure is furnished and installed by others in field.
- Risers available from 3/4" [19mm] to 3" [76mm] diameter with 1/2" [13mm] thick insulation, and 3/4" [19mm] to 2-1/2" [64mm] diameter with 3/4" [19mm] thick insulation.
- Riser length is 111" [2819mm] max, 91" [2311mm] min.
- Back riser location shown. See arrangement drawings for available unit configurations.
- Single supply size 10 and 12 available in top discharge only.
- Factory mounted risers shown.

VH-031

**FIGURE 18 - MODEL VH, VERTICAL CONCEALED HIGH RISE FAN COIL UNIT WITH 79" CABINET**



VH-032


**DIMENSIONS - In [mm]**

UNIT SIZE	A	B	C	SINGLE SUPPLY		DOUBLE SUPPLY		TOP SUPPLY		F
				D	E	D	E	D	E	
03 & 04	18 [457]	24 [610]	16-1/2 [419]	16 [406]	8 [203]	16 [406]	8 [203]	16 [406]	8 [203]	6 [152]
06 & 08	20 [508]	26 [660]	18-1/2 [470]	18 [457]	8 [203]	18 [457]	8 [203]	18 [457]	12 [305]	6 [152]
10 & 12	24 [610]	30 [762]	22-1/2 [572]	-- [--]	-- [--]	22 [559]	8 [203]	22 [559]	12 [305]	8 [203]

NOTES:

- All dimensions are Inches [mm]. Metric values are soft conversion.
- All dimensions are ±1/4 [6mm].
- Tile ring is installed on front of unit as shown, and may be moved to left or right side of unit in field.
- Wiring from electrical entry point to control enclosure is furnished and installed by others in field.
- Risers available from 3/4" [19mm] to 3" [76mm] diameter with 1/2" [13mm] thick insulation, and 3/4" [19mm] to 2-1/2" [64mm] diameter with 3/4" [19mm] thick insulation.
- All piping and insulation between master and slave units is furnished and installed in the field by others.
- Riser length is 111" [2819mm] max, 91" [2311mm] min.
- Back riser location shown. See arrangement drawings for available unit configurations.
- Single supply size 10 and 12 available in top discharge only.
- Slave unit stubout dimension is approximate and varies with riser diameter. Stubout extends approximately 4" from riser tube.
- Water piping connections are 5/8" [16mm] O.D. and drain connection is 7/8" [22mm] O.D.
- Factory mounted risers shown. See drawing VH-105 for shipped loose riser details.

**FIGURE 19 - MODEL VHM, VERTICAL CONCEALED MASTER HIGH RISE FAN COIL UNIT WITH 79" CABINET**



**DIMENSIONS - In [mm]**


UNIT SIZE	A	B	SINGLE SUPPLY		DOUBLE SUPPLY		TOP SUPPLY		E
			C	D	C	D	C	D	
03 & 04	18 [457]	16-1/2 [419]	16 [406]	8 [203]	16 [406]	8 [203]	16 [406]	8 [203]	6 [152]
06 & 08	20 [508]	18-1/2 [470]	18 [457]	8 [203]	18 [457]	8 [203]	18 [457]	12 [305]	6 [152]
10 & 12	24 [610]	22-1/2 [572]	-- [--]	-- [--]	22 [559]	8 [203]	22 [559]	12 [305]	8 [203]

NOTES:

- All dimensions are Inches [mm]. Metric values are soft conversion.
- All dimensions are ±1/4 [6mm].
- Tile ring is installed on front of unit as shown, and may be moved to left or right side of unit in field.
- Wiring from electrical entry point to control enclosure is furnished and installed in the field by others.
- All piping and insulation between slave unit and risers is furnished and installed in the field by others.
- Back connection location shown. See arrangement drawings for available unit configurations.
- Single supply size 10 and 12 available top discharge only.
- All coil and drain connections are "retracted" and braced internally for shipment.
- Coil connections are 5/8" [16mm] O.D. female sweat. Drain "P-trap" is designed to accept 7/8" [22mm] O.D. copper tube.
- Slave units are furnished with factory installed shutoff valves and field connection tubes, unless master unit risers are shipped loose.

VH-033

**FIGURE 20 - MODEL VHS, VERTICAL CONCEALED SLAVE HIGH RISE FAN COIL UNIT WITH 79" CABINET**



NOTES:


1. All dimensions are Inches [mm]. Metric values are soft conversion.
2. All dimensions are  $\pm 1/4$  [6mm].
3. Thermostat mounting— Tile ring is installed on front of unit as shown and may be moved to left or right side of unit in field.
4. Wiring from electrical entry point to control enclosure is furnished and installed by others in field.
5. Risers available from  $3/4$ " [19mm] to  $2-1/2$ " [64mm] diameter with  $1/2$ " [13mm] or  $3/4$ " [19mm] thick insulation.
6. Riser length is 115" [2921mm] max, 100" [2540mm] min.
7. NON-FIRE RATED unit shown with type-X gypsum board at back of slave unit. FIRE RATED units have type-X gypsum board at back of both slave and master units. FIRE RATED unit design has been tested in accordance with UL1479 - Fire Tests Of Through Penetration Fire Stops, and is approved to bear the ETL listing mark for Through Penetration Fire Stop Assemblies.
8. For further fire rating information, refer to the Installation Instructions on page 53.
9. See page 67 for dimensions.
10. Refer to page 39, page 40, page 41 & page 42 for vertical Hi-rise Tandem Master & Tandem Slave configurations.

VH-006-1

**FIGURE 21 - MODEL VHA/VHB, VERTICAL HI-RISE FIRE RATED AND NON-FIRE RATED FCU COMBINATIONS, 79" CABINETS**

DIMENSIONS - In. (mm)						VHA SUPPLY AIR				VHB SUPPLY AIR			
VHA (MASTER)	VHB (SLAVE)	A	B	C	D	SINGLE	DOUBLE	TOP		SINGLE	DOUBLE	TOP	
						E	E	F	G	E	E	F	G
03 or 04	03 or 04	18 (457)	42-1/4 (1073)	16-1/2 (419)	16 (406)	8 (203)	8 (203)	6 (152)	8 (203)	8 (203)	8 (203)	6 (152)	8 (203)
03 or 04	06 or 08	20 (508)	46-1/4 (1175)	18-1/2 (470)	18 (457)	8 (203)	8 (203)	6 (152)	12 (305)	8 (203)	8 (203)	6 (152)	12 (305)
03 or 04	10 or 12	24 (610)	54-1/4 (1378)	22-1/2 (572)	22 (559)	8 (203)	8 (203)	8 (203)	12 (305)		8 (203)	8 (203)	12 (305)
06 or 08	03 or 04	20 (508)	46-1/4 (1175)	18-1/2 (470)	18 (457)	8 (203)	8 (203)	6 (152)	12 (305)	8 (203)	8 (203)	6 (152)	12 (305)
06 or 08	06 or 08												
06 or 08	10 or 12	24 (610)	54-1/4 (1378)	22-1/2 (572)	22 (559)	8 (203)	8 (203)	8 (203)	12 (305)		8 (203)	8 (203)	12 (305)
10 or 12	03 or 04	24 (610)	54-1/4 (1378)	22-1/2 (572)	22 (559)		8 (203)	8 (203)	12 (305)		8 (203)	8 (203)	12 (305)
10 or 12	06 or 08												
10 or 12	10 or 12												

See page 36 for notes.



MODEL TYPE	UNIT SIZE	CABT. HGT.	SINGLE/ DOUBLE SUPPLY			
			W	H	A	B
VHC/VHS/VHM & VHA/VHB	03 or 04	STD.	16 [406]	8 [203]	17-11/16 [449]	9-11/16 [246]
		79" CABT.	18 [457]	12 [305]	19-11/16 [500]	13-11/16 [348]
	06 or 08	STD.	18 [457]	8 [203]	19-11/16 [500]	9-11/16 [246]
		79" CABT.	22 [559]	14 [356]	23-11/16 [602]	15-11/16 [398]
	10 or 12	STD.	N/A	N/A	N/A	N/A
		79" CABT.	N/A	N/A	N/A	N/A


MODEL TYPE	UNIT SIZE	CABT. HGT.	SINGLE/ DOUBLE SUPPLY			
			W	H	A	B
VHA/VHB	03 or 04 mated to 06 or 08	STD.	18 [457]	12 [305]	19-11/16 [500]	13-11/16 [348]
		79" CABT.	18 [457]	8 [203]	19-11/16 [500]	9-11/16 [246]
	03 or 04 mated to 10 or 12	STD.	22 [559]	14 [356]	23-11/16 [602]	15-11/16 [398]
		79" CABT.	N/A	N/A	N/A	N/A
	06 or 08 mated to 10 or 12	STD.	22 [559]	14 [356]	23-11/16 [602]	15-11/16 [398]
		79" CABT.	N/A	N/A	N/A	N/A

NOTES:


1. All dimensions are Inches [mm]. Metric values are soft conversion.
2. All dimensions are ±1/4 [6mm].
3. Discharge grilles are shipped loose for field installation.
4. Construction is aluminum frame and blades.
5. Standard finish is powder coat baked enamel. Color is "Pearl White Satin".
6. Installation of grilles on adjacent unit sides may require furring one side away from unit to prevent interference of frames.
7. Mounting hardware included.

74-80020



FIGURE 22 - MODEL VH, VERTICAL HIGH RISE COIL UNIT, ALUMINUM DISCHARGE GRILLE




**FIGURE 23 - MODEL VHC/VHM/VHA VERTICAL HIGH RISE FAN COIL UNIT ARRANGEMENT DESIGNATIONS**



**FIGURE 24 - MODEL VHC W/O RISERS & VHS/VHB VERTICAL HIGH RISE FAN COIL UNITS, UNIT ARRANGEMENT DESIGNATIONS**




F = FRONT  
T = TOP  
B = BACK  
L = LEFT  
R = RIGHT  
O = NONE



**UNIT SIDE DESIGNATIONS**


**NOTES:**

1. RETURN AIR AND ACCESS ARE ALWAYS ON FRONT OF UNIT.
2. THIS DRAWING SHOWS AVAILABLE RETURN AND OUTSIDE AIR INLET LOCATIONS.
3. SEE ARRANGEMENT DRAWINGS FOR COMPLETE UNIT RISER, SUPPLY, AND RETURN CONFIGURATION DETAILS.
4. OUTSIDE AIR INLET LOCATION IS ALWAYS LAST CHARACTER IN ARRANGEMENT CODE.
5. VHC UNIT WITH OPTIONAL RISER CHASE SHOWN. OUTSIDE AIR LOCATION DESIGNATIONS ARE TYPICAL FOR ALL VH MODELS.




VH-018

**FIGURE 25 - MODEL VH VERTICAL HIGH RISE COIL UNIT OUTSIDE INLET DIMENSIONS**



**TYPICAL UNIT ARRANGEMENTS**

SHOWN ABOVE NON-FIRE RATED



**TYPICAL UNIT ARRANGEMENTS**

**LEGEND**


- EXTERIOR WALL
- INTERIOR WALL
- TANDEM MASTER & TANDEM SLAVE FIRE RATED
- TANDEM MASTER & TANDEM SLAVE NON-FIRE RATED

← AIR FLOW

- A MASTER UNIT
- B SLAVE UNIT


**NOTE:**

1. FOR OTHER POSSIBLE COMBINATIONS SEE
2. FIRE RATED UNITS SHOWN NON-FIRE RATED IS STANDARD.
3. SEE TANDEM MASTER & TANDEM SLAVE INSTALLATION INSTRUCTIONS ON PAGES page 53 - page 55.
4. SIGHT AND SOUND Baffles PROVIDED AS REQUIRED.




VH-043

**FIGURE 26 - MODEL VHM/VHA/VHC TANDEM MASTER & TANDEM SLAVE UNIT CONFIGURATION FAN COIL UNIT**



6

**FIGURE 27 - ASSEMBLY INSTRUCTIONS RETURN PANEL WITH LATCHES, QUICK OPENING OR TAMPER PROOF, MODEL VHC/VHM/VHS HIGH RISE FCU**




**NOTES:**

1. All risers and valves are shipped with protective caps. These caps should remain in place until installation of the unit.
2. Each valve is supplied with an O-ring that is bagged and shipped loose for field installation by others.
3. All risers are factory tested, and guaranteed to be leak free at time of shipment.
4. Riser information shown shall reflect matching unit identification labels.
5. VHS, Slave Units will have mirror image orientation and will be labeled in units.
6. Condensate P-Trap and hose clamps ships installed in unit for field connections to drain riser.

**FIGURE 28 - PREPARATION INSTRUCTIONS FOR MODEL VHC/VHM VERTICAL HIGH RISE FCU "SHIP LOOSE" RISER ASSEMBLIES**

THIS PAGE INTENTIONALLY LEFT BLANK




**DIMENSIONS - In[mm]**

UNIT SIZE	W	A	B	C	UNIT SIZE (6)	W	A	B	C
03/04	17-1/2 [445]	24-1/8 [613]	15 [381]	1-1/4 [32]	0306-0408	19-1/2 [495]	24-1/8 [613]	15 [381]	2-1/4 [57]
06/08	19-1/2 [495]	24-1/8 [613]	15 [381]	2-1/4 [57]	0310-0412	23-1/2 [597]	24-1/8 [613]	21 [533]	1-1/4 [32]
10/12	23-1/2 [597]	28-1/2 [724]	21 [533]	1-1/4 [32]	0610-0812	23-1/2 [597]	24-1/8 [613]	21 [533]	1-1/4 [32]

NOTES:

1. All dimensions are Inches [mm]. Metric values are soft conversion.
2. All dimensions are ±1/4" [6mm].
3. Installed wall panels extends approximately 3/4" [19mm] from finished wall surface.
4. Standard finish is Powder Coat Baked Enamel, color is "Pearl White Satin".
5. Mounting hardware is factory installed. Refer to instructional drawing VH-106 for details.
6. Sizes shown are for "up-sized" cabinet units used in "Enviro-Pac" pairs.

**FIGURE 29 - MODEL VH VERTICAL HIGH RISE FAN COIL UNIT STANDARD SURFACE MOUNT WALL PANEL**



6

**DIMENSIONS - In[mm]**


UNIT SIZE	A	B	C	D	E	F	G	UNIT SIZE (6)	A	B	C	D	E	F	G
03/04	17-5/8 [448]	19-7/8 [505]	17-7/16 [443]	24-1/8 [613]	15 [381]	1-1/4 [32]	18-1/8 [460]	0306-0408	19-5/8 [498]	21-7/8 [556]	19-7/16 [494]	24-1/8 [613]	15 [381]	2-1/4 [57]	20-1/8 [511]
06/08	19-5/8 [498]	21-7/8 [556]	19-7/16 [494]	24-1/8 [613]	15 [381]	2-1/4 [57]	20-1/8 [511]	0310-0412	23-5/8 [600]	25-7/8 [657]	23-7/16 [595]	24-1/8 [613]	21 [533]	1-1/4 [32]	24-1/8 [613]
10/12	23-5/8 [600]	25-7/8 [657]	23-7/16 [595]	28-1/2 [724]	21 [533]	1-1/4 [32]	24-1/8 [613]	0610-0812	23-5/8 [600]	25-7/8 [657]	23-7/16 [595]	24-1/8 [613]	21 [533]	1-1/4 [32]	24-1/8 [613]

NOTES:

1. All dimensions are Inches [mm]. Metric values are soft conversion.
2. All dimensions are ±1/4" [6mm].
3. Finished wall surface must be furred out a minimum of 2" [51mm] from front of unit.
4. Standard finish is powder coat baked enamel. Color is "Pearl White Satin".
5. Mounting hardware is factory installed. Refer to assembly instructions on page 43 for details.
6. Sizes shown are for "up-sized" cabinet units used in Tandem Master & Tandem Slave pairs.

VH-014

**FIGURE 30 - RECESSED WALL PANEL MODEL VH VERTICAL HIGH RISE FAN COIL UNIT**



**DIMENSIONS - In[mm]**

UNIT SIZE	W	A	B	C	UNIT SIZE (8)	W	A	B	C
03/04	17-1/2 [445]	24-1/8 [613]	15 [381]	1-1/4 [32]	0306-0408	19-1/2 [495]	24-1/8 [613]	15 [381]	2-1/4 [57]
06/08	19-1/2 [495]	24-1/8 [613]	15 [381]	2-1/4 [57]	0310-0412	23-1/2 [597]	24-1/8 [613]	21 [533]	1-1/4 [32]
10/12	23-1/2 [597]	28-1/2 [724]	21 [533]	1-1/4 [32]	0610-0812	23-1/2 [597]	24-1/8 [613]	21 [533]	1-1/4 [32]

NOTES:

- All dimensions are Inches [mm]. Metric values are soft conversion.
- All dimensions are ±1/4" [6mm].
- Installed wall panels extends approximately 3/4" [19mm] from finished wall surface.
- Standard finish is Powder Coat Baked Enamel, color is "Pearl White Satin".
- Mounting hardware is factory installed. Refer to assembly instructions on page for details.
- Actual installed thermostat height is determined by unit installation method and may vary.
- Thermostat is shipped loose for field installation by others.
- Sizes shown are for "up-sized" cabinet units used in Tandem Master & Tandem Slave pairs.

VH-047

**FIGURE 31 - MODEL VH VERTICAL HIGH RISE FAN COIL UNIT STANDARD RETURN WALL PANEL WITH ADA THERMOSTAT**

**TABLE 1 - DISCHARGE REGISTER PERFORMANCE DATA, VH STANDARD FCU 88" CABINET, SINGLE AND DOUBLE SUPPLY**

SINGLE SUPPLY									
UNIT SIZE	CFM (SEE NOTE 5)	REGISTER DATA							
		W (IN.)	H (IN.)	Pv (in W.G.)	Pt (in W.G.)	Ps (IN W.G.)	NC	THROW (FT)	DROP (FT)
03	375	16	8	0.013	0.0370	0.0240	<20	16-36	9.5
04	450	16	8	0.018	0.0524	0.0344	<20	19-38	10
06	616	18	12	0.017	0.0523	0.0353	<20	18-45	13
08	860	18	12	0.024	0.0698	0.0458	26	26-52	16
10	966	22	14	0.017	0.0524	0.0354	21	27-62	21
12	1350	22	14	0.024	0.0697	0.0457	26	33-69	23

DOUBLE SUPPLY									
UNIT SIZE	CFM (SEE NOTE 5)	REGISTER DATA							
		W (IN.)	H (IN.)	Pv (in W.G.)	Pt (in W.G.)	Ps (IN W.G.)	NC	THROW (FT)	DROP (FT)
03	375	16	8	0.006	0.0170	0.0110	<20	11-24	10
04	450	16	8	0.008	0.0230	0.0150	<20	11-27	10.5
06	616	18	12	0.003	0.0072	0.0042	<20	10-35	11.5
08	860	18	12	0.006	0.0170	0.0110	<20	12-37	12
10	966	22	14	0.006	0.0170	0.0110	<20	13-42	12
12	1350	22	14	0.008	0.0230	0.0150	<20	14-45	14

**NOTES:**

1. NC data is at 0° deflection. For 22.5° deflection, add 1 NC. For 45° deflection, add 7 NC.
2. Throws are for velocities of 50 and 150 FPM at 0° deflection.
3. For 22.5° and 45° deflection, multiply by 0.67.
4. Drops are at 0° deflection. For 22.5° deflection, multiply by 0.85. For 45° deflection, multiply by 0.66.
5. Register Data is based on zero static and CRM show at high speed motor operation.
6. Data above does not reflect optional opposed blade damper information.

**TABLE 2 - DISCHARGE REGISTER PERFORMANCE DATA, VH STANDARD FCU 79" CABINET, SINGLE AND DOUBLE SUPPLY**

SINGLE SUPPLY									
UNIT SIZE	CFM (SEE NOTE 5)	REGISTER DATA							
		W (IN.)	H (IN.)	Pv (in W.G.)	Pt (in W.G.)	Ps (IN W.G.)	NC	THROW (FT)	DROP (FT)
03	375	16	8	0.013	0.0370	0.0240	<20	13-32	10
04	450	16	8	0.018	0.0524	0.0344	23	20-39	10.5
06	616	18	8	0.026	0.0765	0.0505	32	20-39	10.5
08	860	18	8	0.054	0.1624	0.1084	39	32-54	17

DOUBLE SUPPLY									
UNIT SIZE	CFM (SEE NOTE 5)	REGISTER DATA							
		W (IN.)	H (IN.)	Pv (in W.G.)	Pt (in W.G.)	Ps (IN W.G.)	NC	THROW (FT)	DROP (FT)
03	375	16	8	0.003	0.0072	0.0042	<20	8-25	9
04	450	16	8	0.005	0.0160	0.0110	<20	9-25	10
06	616	18	8	0.007	0.0180	0.0110	<20	13-30	10
08	860	18	8	0.015	0.0380	0.0230	21	18-39	11
10	966	22	8	0.015	0.0380	0.0230	<20	17-42	12.5
12	1350	22	8	0.019	0.0560	0.0370	21	21-45	14

**NOTES:**

1. NC data is at 0° deflection. For 22.5° deflection, add 1 NC. For 45° deflection, add 7 NC.
2. Throws are for velocities of 50 and 150 FPM at 0° deflection.
3. For 22.5° and 45° deflection, multiply by 0.67.
4. Drops are at 0° deflection. For 22.5° deflection, multiply by 0.85. For 45° deflection, multiply by 0.66.
5. Register Data is based on zero static and CRM show at high speed motor operation.
6. Data above does not reflect optional opposed blade damper information.


USE THIS CHART TO DETERMINE LENGTH OF SLOT NEEDED,  
LENGTH IS MEASURED PARALLEL TO UNIT HEIGHT.  
SEE ILLUSTRATIONS TO THE RIGHT.

UNIT SIZE	PIPE DIAMETER	INSTALLATION METHOD			
		(A)	(B)	(C)	(D)
03-04	3/4 TO 1-1/2	11-11/16	18-9/16	4-5/8	8-11/16
	2 TO 3	13-1/16	20	6-1/16	10
	ADD PER INCH OVER 100	5/8	11/16	1/4	11/16
06-08	3/4 TO 1-1/2	11-3/4	18-7/16	5-1/2	8-11/16
	2 TO 3	12-15/16	19-7/8	6	10
	ADD PER INCH OVER 100	9/16	11/16	1/4	11/16
10-12	3/4 TO 1-1/2	11-5/16	18-1/4	4-5/16	8-11/16
	2 TO 3	12-11/16	19-11/16	5-13/16	10
	ADD PER INCH OVER 100	1/2	9/16	1/4	11/16


USE THIS CHART TO DETERMINE WIDTH OF SLOT NEEDED,  
WIDTH IS MEASURED PERPENDICULAR TO UNIT HEIGHT.  
SEE ILLUSTRATIONS TO THE RIGHT.

PIPE DIAMETER		SLOT WIDTH			
		(A)	(B)	(C)	(D)
3/4"	2 PIPE	2-3/4"	N/A	8-3/4"	USE (C)
	4 PIPE	N/A	2-3/4"	16"	USE (C)
1"	2 PIPE	3"	N/A	9"	USE (C)
	4 PIPE	N/A	3"	16-1/4"	USE (C)
1-1/4"	2 PIPE	3-1/4"	N/A	9-1/4"	USE (C)
	4 PIPE	N/A	3-1/4"	16-1/2"	USE (C)
1-1/2"	2 PIPE	3-1/2"	N/A	9-1/2"	USE (C)
	4 PIPE	N/A	3-1/2"	16-3/4"	USE (C)
2"	2 PIPE	4"	N/A	10"	USE (C)
	4 PIPE	N/A	4"	17-1/4"	USE (C)
2-1/2"	2 PIPE	4-1/2"	N/A	10-1/2"	USE (C)
	4 PIPE	N/A	4-1/2"	17-3/4"	USE (C)
3"	2 PIPE	5"	N/A	11"	USE (C)
	4 PIPE	N/A	5"	18-1/4"	USE (C)

**NOTE:**  
SOME UNITS MAY HAVE DIFFERENT LENGTH AND DIAMETERS OF PIPE.  
ALWAYS USE THE LONGEST AND/OR LARGEST DIAMETER  
WHEN DETERMINING SLOT LENGTHS AND WIDTHS.



**FIGURE 32 - SUGGESTED RISER FLOOR OPENINGS VHC & VHM**



**FLOOR TO FLOOR HEIGHT:**  
 DISTANCE FROM THE TOP OF ONE SLAB  
 TO THE TOP OF THE SLAB ON THE NEXT FLOOR.

**CLEARANCE HEIGHT:**  
 HEIGHT AVAILABLE ON ONE FLOOR,  
 FLOOR TO FLOOR HEIGHT LESS THE SLAB THICKNESS.

**ROOM RISER HEIGHT:**  
 DISTANCE FROM THE FLOOR TO THE TOP OF THE RISER,  
 ALL RISERS EXTEND 3" BEYOND THE TOP OF THE UNIT.

**UNIT HEIGHT:**  
 DISTANCE FROM FLOOR TO THE TOP OF THE UNIT.

**RISER LENGTH:**  
 OVERALL LENGTH OF THE RISERS (SPECIFIED ON ORDER).  
 USE THE FORMULA BELOW TO DETERMINE RISER LENGTH.  
 RISERS ARE AVAILABLE IN LENGTHS FROM 91" TO 120" IN  
 1" INCREMENTS.

**SLAB THICKNESS:**  
 THICKNESS OF FLOOR, INCLUDING ANY HANGING OBSTRUCTIONS,  
 SEE CONTRACTORS PLANS TO DETERMINE THICKNESS.

**RISER TAIL LENGTH:**  
 DISTANCE THAT RISERS EXTEND BELOW UNIT.

VH-110

**NOTE:**  
 IF RECOMMENDED RISER LENGTH EXCEEDS 120",  
 RISER EXTENSIONS WILL BE REQUIRED.

**FIGURE 33 - RISER TERMINOLOGY, MODEL VHC, VHM, VHA UNITS**

## VERTICAL HI-RISE TANDEM UNITS VHA/VHB INSTALLATION INSTRUCTIONS

### Receipt & Initial Installation

#### General

This publication details the installation requirements for the Enviro-Pac dual unit configuration of the Vertical High Rise, VH, unit assembly. Use of this document for systems or products not manufactured or supplied by ENVIRO-TEC shall not be applicable.

All products covered by this manual have been tested in accordance with UL1479 (2012) - Fire Tests Of Through Penetration Fire Stop Assemblies. Specific information about the ENVIRO-PAC VHA/VHB UL1479 (2012) listing may be viewed on the Warnock Hersey Listed Product Directory at <https://whdirectory.intertek.com>. Reference WH file number JCI/PF60-01.

Specific ETL listed model numbers may be found in the current ETL Listed Mark Directory at <http://www.intertek.com/directories/>.

For other VH product installation and operational instructions, refer to IOM-FCUVH.

The Installation Instructions found within this manual have been specifically drawn and detailed to meet the requirements of UL1479 (2012). Some jurisdictions may have additional installation requirements above and beyond those detailed in this document; consult with the authority having jurisdiction for specific additional requirements. In all cases, the instructions detailed in this document must be followed to maintain the UL 1479 (2012) fire rating.

#### Installation

1. In order to achieve the 1 hour fire rating, ENVIRO-PAC unit assembly must be installed into a minimum 1-hour fire rated wall assembly of gypsum and steel stud, gypsum and wood stud, concrete, or masonry construction with a minimum overall thickness of 4-3/4". The wall assembly shall extend into the unit spacer plate. When applicable, attach studs of the wall to the unit spacer plate with sheet metal screws spaced nominally 12" O.C. When built of gypsum construction, the following minimum requirements must be met.
  - a. Studs – Wood or steel studs nominal 3-1/2" thick, spaced maximum 24" O.C.

- b. Gypsum Board – Minimum 5/8" Type X Gypsum board with a minimum of one layer. Gypsum board must be installed on each side of the wall assembly.

2. Place unit assembly in its desired location. Check riser number, floor number, room number, and unit tag number against the tag label on the unit, making sure that the unit assembly is installed with the space between the two units centered in the wall between each room.
3. Anchor unit assembly to floor through unit bottom. Due to floor leveling, some shimming may be necessary so unit is plumb and square to floor/ceiling.
4. Install floor stud reception channels up to unit sides at the connector plate.
5. Install ceiling stud reception channel over the unit assembly, leaving space for riser penetration.
6. Install the wall studs into the recess in the unit assembly using #6 x 1/2 drywall screws spaced as necessary.



***Avoid placing screws where they may penetrate the risers, coil, piping, or electrical system.***

7. Install balance of the studs into ceiling/floor reception channels at a spacing to meet project specifications and local, state, or national codes. In no cases should stud spacing be greater than 24" O.C.
8. Install studs from top of unit to ceiling. Locates studs at each unit corner.
9. Make necessary electrical and plumbing connections to unit.
10. Two installation configurations may be used for the ENVIRO-PAC units. The following details standard installation per *Figure 53 on page 54*.
  - a. Install minimum 5/8" Type X gypsum board to all exposed sides of the unit exterior, including top and front. Gypsum panels may be applied directly to unit casing or may be furred out for plumbness. Any supply air, outside air, or thermostat openings shall be let-in as necessary.

- b. The gypsum panel installed to the face of the unit should be applied directly to the front of the unit, unless a wall recessed return air grille is used, in which case this panel will be furred-out. Any supply air, return air, or thermostat openings shall be let-in as necessary.
  - c. Attach gypsum board to unit with sheet metal screws spaced 8" O.C. around the perimeter and 12" O.C. in the field, ensuring that screws are not located where they might penetrate interior working of unit.
  - d. Gypsum board shall be tightly butted against the wall assembly on all exposed sides, including top of unit.
11. For alternate installation per *Figure 54 on page 54*, unit framing must be installed to top of unit.
- a. Install minimum 25 GA, nominal 3-1/2" wide, steel track to the top of the fan coil unit, at top front and two top sides as shown in *Figure 54 on page 54*.
  - b. Attach steel track using sheet metal screws spaced 12" O.C.
  - c. Install identical steel track to the ceiling or floor assembly using appropriate anchors. Friction fit minimum 25 GA nominal 3-1/2" steel studs into the top and bottom track and secure with pan head screws.
  - d. Install one stud at each corner of the fan coil unit.
  - e. Install gypsum board to the front and side of the fan coil unit as described in Step 10.
  - f. Extend the gypsum board to the ceiling or floor assembly, attaching to steel studs and track with Type S screws spaced maximum 8" O.C.
12. Risers shown in the standard location. Risers may be installed on the left or right side of Unit A. Wall construction should remain the same, regardless of riser location.




FIGURE 34 - STANDARD INSTALLATION

Attached to pre-existing ceiling or floor assembly







FIGURE 35 - ALTERNATE INSTALLATION

-  = 5/8" TYPE-X GYPSUM BOARD, FIELD SUPPLIED
-  = 5/8" TYPE-X GYPSUM BOARD, FACTORY SUPPLIED



6




FIGURE 36 - MOUNTING DETAILS

SHEET 2 OF 2  
PX-70-0001  
LD13947

The following factors can be used to convert from English to the most common SI Metric values.

**TABLE 3 - SI METRIC CONVERSION**

MEASUREMENT	MULTIPLY ENGLISH UNIT	BY FACTOR	TO OBTAIN METRIC UNIT
Capacity	Tons Refrigerant Effect (ton)	3.516	Kilowatts (kW)
Power	Horsepower	0.7457	Kilowatts (kW)
Flow Rate	Gallons / Minute (gpm)	0.0631	Liters / Second (l/s)
Length	Feet (ft)	0.3048	Meters (m)
	Inches (in)	25.4	Millimeters (mm)
Weight	Pounds (lbs)	0.4538	Kilograms (kg)
Velocity	Feet / Second (fps)	0.3048	Meters / Second (m/s)
Pressure Drop	Feet of Water (ft)	2.989	Kilopascals (kPa)
	Pounds / Square Inch (psi)	6.895	Kilopascals (kPa)

## TEMPERATURE

To convert degrees Fahrenheit (°F) to degrees Celsius (°C), subtract 32° and multiply by 5/9 or 0.5556.

Example:  $(45.0^{\circ}\text{F} - 32^{\circ}) \times 0.5556 = 27.2^{\circ}\text{C}$

To convert a temperature range (i.e., a range of 10°F) from Fahrenheit to Celsius, multiply by 5/9 or 0.5556.

Example:  $10.0^{\circ}\text{F range} \times 0.5556 = 5.6^{\circ}\text{C range}$

## **APPENDIX COMPONENT INSTALLATION, OPERATION & MAINTENANCE MANUALS**

---

Fan Coil Relay Board (FCRB) Installation, Operation & Maintenance (Units Shipped Prior to 3/31/2017)

---

Fan Relay Board 2 (FRBii) Installation, Operation & Maintenance (Units Shipped 3/31/2017 to Present)

---

Fan Coil EC Motor Control (G3) Installation, Operation & Maintenance

---

Electric Heat, All Products Installation, Operation & Maintenance

---

Analog Thermostats – Data and Instructions

---

Digital Thermostat (D-Series) – Installation Guide

---

Digital Thermostat (D-Series) – Operating Manual

---

Programmable Thermostat (P-Series) – Installation Guide

---

Programmable Thermostat (P-Series) – Operating Manual

---

N-Series TEC3000 – Installation Instructions

---

**For the supplemental installation, operation and maintenance manuals listed above, please contact your local Sales Representative or visit [www.enviro-tec.com/literature/iom](http://www.enviro-tec.com/literature/iom).**

ENVIRO-TEC is a registered trademark of Johnson Controls in the United States of America and other countries.  
Other trademarks used herein may be trademarks or registered trademarks of other companies.

Catalog: ET115.24-NOM4 (1220) Supersedes ET115.24-NOM4 (820)  
© 2020 Johnson Controls  
[www.enviro-tec.com](http://www.enviro-tec.com)

