

### **R-410A** MODELS: YC090 Through 300 YD120 Through 240 YE090 60 Hertz 7.5 - 25 Ton





8 9 11

**TABLE OF CONTENTS** Phasing . . . . .

omenclature	2
eneral	)
enewal Parts	5
gency Approvals	5
spection	;
Physical Data 4	
stallation	;
Preceding Installation 5	
Limitations	
Location	,
Clearances	'
Rigging 7	'

Operation	-	-		-		-	22
Sequence of Operation							22
Cooling Sequence Of Operation							22
Control Board Navigation Components							24
Typical Wiring Diagrams							36
Start-Up Sheet							44
			• •		•••		

Crankcase Heater .....

### LIST OF TABLES

1	YC090-300, YD120-240, and YE090 Physical Data 4
2	Unit Application Data 5
	Corner Weights & Center of Gravity
4	Minimum Clearances
5	Electrical Data - Outdoor Unit - AC Without Powered Convenience Outlet
6	Electrical Data - Outdoor Unit - AC With Powered Convenience Outlet

7	YC090, YE090, YC/YD120, YC/YD150 Unit Height Dimensions	19
8	YC/YD180, YC/YD240 and YC300 Unit Height Dimensions	21
9	Piping And Electrical Connection Sizes (Inches)	21
10	Smart Equipment <sup>™</sup> UCB Details	25
11	Cable for FC Buses and SA Buses in Order of Preference	30

## LIST OF FIGURES


1	Corner Weights & Center Of Gravity    6      Typical Rigging    7
3	Typical Simplified Field Wiring Diagram – NC180 thru 240
	Evaporator with YC150 thru 240 Condenser 13
4	Typical NC120 - 240 Liquid Line Solenoid Wiring 13
5	Typical Simplified Field Wiring Diagram - NC300
	Evaporator Unit with YC300 Condenser Unit 14
6	Typical NC300 Liquid Line Solenoid Wiring
7	Typical Simplified Field Wiring Diagram – ND180 thru 240
	Evaporator with YD150 thru 240 Condenser
8	Typical Simplified Field Wiring Diagram – NL090
	Evaporator with YC090/YE090 Condenser
9	Typical Simplified Field Wiring Diagram – NL120 thru 240
	Evaporator with YC120 thru 240 Condenser 17
10	Typical NL120 - 240 Liquid Line Solenoid Wiring 17
11	Typical Simplified Field Wiring Diagram – NM120 thru 240
	Evaporator with YD120 thru 240 Condenser
12	YC090, YE090, YC/YD120, YC/YD150 Unit Dimensions. 19
13	YC/YD180, YC/YD240 & YC300 Unit Dimensions and

1 Piping & Electrical Dimensions ...... 20

14 15 16 17 18 20 21 22 23 24 25 26 27 28 20 31	Unit Control Board	24 25 31 32 23 33 33 34 45 56 78 90 41
	Typical YC180 Condensing Unit Wiring Diagram	
33		43

#### 5734682-YIM-B-0519

## Nomenclature



## **Configured Split Condenser Model Number Nomenclature**

### General

These condensing units are designed for outdoor installation on a roof or at ground level. Every unit is completely piped and wired at the factory and is shipped ready for immediate installation. Only the liquid and suction lines to the evaporator coil, the filter drier, the thermostat wiring and the main power wiring are required to complete the installation. Each unit is dehydrated, evacuated, leak tested and pressure tested at 450 psig before being pressurized with a holding charge of refrigerant R-410A for shipment and/or storage.

All controls are located in the front of the unit and are readily accessible for maintenance, adjustment and service. All wiring (power and control) can be made through the front of the unit.

## **A** CAUTION

This Split-System (Air Condensing / Heat Pump / Air Handling) unit is one component of an entire system. As such it requires specific application considerations with regard to the rest of the system (air handling unit, duct design, condensing unit, refrigerant piping and control scheme).

Failure to properly apply this equipment with the rest of the system may result in premature failure and/or reduced performance / increased costs. Warranty coverage specifically excludes failures due to improper application and Ducted Systems specifically disclaims any liability resulting from improper application.

Please refer to the equipment Technical Guide, Installation Manual and the piping applications bulletin 247077 or call the applications department for Ducted Systems @ 1-877-874-SERV for guidance.

### Safety Considerations

Installer should pay particular attention to the words: *NOTE*, *CAUTION*, and *WARNING*. <u>Notes</u> are intended to clarify or make the installation easier. <u>Cautions</u> are given to prevent equipment damage. <u>Warnings</u> are given to alert installer that personal injury and/or equipment damage may result if installation procedure is not handled properly.

# 

Improper installation may create a condition where the operation of the product could cause personal injury or property damage. Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to this manual for assistance or for additional information, consult a qualified contractor, installer or service agency.

# 

Before performing service or maintenance operations on unit, turn off main power switch to unit. Electrical shock could cause personal injury. Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to this manual. For assistance or additional information consult a qualified installer, service agency or the gas supplier.

# **A** CAUTION

This system uses R-410A Refrigerant which operates at higher pressures than R-22. No other refrigerant may be used in this system. Gage sets, hoses, refrigerant containers and recovery systems must be designed to handle R-410A. If you are unsure, consult the equipment manufacturer. Failure to use R-410A compatible servicing equipment may result in property damage or injury.

### Reference

This instruction covers the installation and operation of the basic condensing unit. For refrigerant piping installation instructions refer to document 247077 "Application Data - General Piping Recommendations for Split System Air Conditioning and Heat Pumps". For information on the installation and operation of the evaporator blower units, refer to the Installation Manual that comes with the unit.

All accessories come with a separate Installation Manual.

## **Renewal Parts**

Contact your local Source 1 Distribution Center for authorized replacement parts.

## **Agency Approvals**

Design certified by CSA as follows:

- 1. For use as a cooling unit.
- 2. For outdoor installation only.

### Inspection

As soon as a unit is received, it should be inspected for possible damage during transit. If damage is evident, the extent of the damage should be noted on the carrier's freight bill. A separate request for inspection by the carrier's agent should be made in writing.

# A CAUTION

This product must be installed in strict compliance with the enclosed installation instructions and any applicable local, state and national codes including, but not limited to, building, electrical, and mechanical codes.

### **Physical Data**

### Table 1: YC090-300, YD120-240, and YE090 Physical Data

Componer							Models					
Componer	IC	YC090	YE090	YC120	YD120	YC150	YD150	YC180	YD180	YC240	YD240	YC300
Nominal Tonr	nage	7.5	7.5	10	10	12.5	12.5	15	15	20	20	25
Refrigerant												
Refrigerant type		R-410A										
Holding charge (lb) <sup>1</sup>		1.0	1	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0	1.0
Operating charge (lb) <sup>2</sup>	System #1	14.0	14.8	19.25	9.9	24.0	11.5	27.0	13.5	33.5	18.8	35
Operating charge (ib)	System #2				9.9		11.5		13.5		18.8	
Dimensions (inches)												
Length		59.1	59.1	59.1	59.1	59.1	59.1	59.1	59.1	59.1	59.1	59.1
Width		31.9	31.9	31.9	31.9	31.9	31.9	64.1	64.1	64.1	64.1	64.1
Height		44.5	44.5	50.0	50.0	50.0	50.0	44.5	44.5	50.0	50.0	50.0
Weights (lb)												
Shipping		390	386	499	493	499	493	914	903	945	930	945
Operating		387	383	497	490	497	490	909	898	942	927	942
Compressors <sup>3</sup>								1				
Туре		Single scroll	Single Scroll	Tandem scroll								
Quantity		1	1	1	2	1	2	1	2	1	2	1
N	System #1	7.5	7.5	10	5	12.5	6.3	15	7.5	20	10	25
Nominal capacity (tons)	System #2				5		6.3		7.5		10	
0	System #1	1	2	2	1	2	1	2	1	2	1	2
Capacity stages	System #2				1		1		1		1	
System data	-											
No. refrigeration circuits		1	1	1	2	1	2	1	2	1	2	1
Suction line OD (in.)		1 1/8	1 1/8	1 3/8	1 1/8	1 3/8	1 1/8	1 5/8	1 1/8	1 5/8	1 3/8	1 5/8
Liquid line OD (in.)		5/8	5/8	7/8	5/8	7/8	5/8	7/8	5/8	7/8	5/8	7/8
Outdoor coil data												
Face area (Sq. Ft.)		23.8	23.8	29.0	29.0	29.0	29.0	47.5	47.5	58.1	58.1	58.1
Rows		1	1	1	1	1	1	1	1	1	1	1
Fins per inch		23	23	23	23	23	23	23	23	23	23	23
Tube diameter (in./MM)		0.71 / 18	0.71 / 18	0.71 / 18	0.71 / 18	0.71 / 18	0.71/18	0.71 / 18	0.71/18	0.71 / 18	0.71 / 18	0.71/18
Circuitry type		2-pass										
Refrigerant control												
Condenser fan data												
No. fans/diameter (in.)		2/24	2/24.	2/24	2/24	2/24	2/24	4/24	4/24	4/24	4/24	4/24
Туре		Axial										
Drive type		Direct										
No. speeds		1	1	1	1	1	1	1	1	1	1	1
Number of motors	System #1	2	2	2	2	2	2	4	2	4	2	4
	System #2								2		2	
Motor HP (ea.)		1/3	1/3	3/4	3/4	3/4	3/4	1/3	3/4	3/4	3/4	3/4
Rotation <sup>4</sup>		CW										
RPM		850	850	1100	1100	1100	1100	850	1100	1100	1100	1100
	System #1	7500	7500	9800	9800	9800	9800	15000	9800	19600	9800	19600
Nominal CFM	System #2								9800		9800	

Holding Charge is the amount in the unit as shipped from the factory.
 Includes matched indoor blower unit with 25 ft of piping.
 All compressors include crankcase heaters.
 When viewing the shaft end of the motor.

### Table 2: Unit Application Data

	208/230-3-60	187/252			
Voltage Variation <sup>1</sup> Min. / Max.	460-3-60	432/504			
	575-3-60	540/630			
Ambient Air on Co Min. /Ma		40°F/125°F <sup>2</sup>			
Suction Pressure at C Corresponding Temp Min. / M	106.6 psig / 156.6 psig 32.0 °F / 55.0 °F				

 Utilization range "A" in accordance with AHRI Standard 110.
 These units can operate in an ambient temperature of 125°F providing the wet bulb temperature of the air enter-

ing the evaporator coil does not exceed 67°F. Unit can operate to 0°F if equipped with a low ambient kit.

### Installation

### **Preceding Installation**

If a factory option convenience outlet is installed, the weatherproof outlet cover must be field installed. The cover shall be located in the unit control box. To install the cover, remove the shipping label covering the convenience outlet, follow the instructions on the back of the weatherproof cover box, and attach the cover to the unit using the (4) screws provided.

## **A** CAUTION

208/230-3-60 and 380/415-3-50 units with factory installed Powered Convenience Outlet Option are wired for 230v and 415v power supply respectively. Change tap on transformer for 208-3-60 or 380-3-50 operation. See unit wiring diagram.

### Limitations

These units must be installed in accordance with all national and local safety codes. If no local codes apply, installation must conform to the appropriate national codes. Units are designed to meet National Safety Code Standards. If components are to be added to a unit to meet local codes, they are to be installed at the dealer's and/or the customer's expense.

### Location

Use the following guidelines to select a suitable location for both the condensing unit and the evaporator.

- 1. The condensing unit is designed for outdoor installation only.
- 2. The condenser fans are the propeller type and are not suitable for use with ductwork in the condenser air stream.
- 3. The condensing unit and the evaporator should be positioned to minimize the number of bends in the refrigerant piping.
- 4. The condensing unit should be as close to the evaporator as practical.
- 5. The condensing unit should not be installed where normal operating sounds may be objectionable.
- 6. The evaporator should be located within the building, either outside or inside the conditioned space.

### **Rooftop Locations**

Be careful not to damage the roof. Consult the building contractor or architect if the roof is bonded. Choose a location with adequate structural strength to support the unit.

The condensing unit must be mounted on level supports. The supports can be channel iron beams or wooden beams treated to reduce deterioration.

Minimums of two (2) beams are required to support each unit. The beams should: (1) be positioned perpendicular to the roof joists. (2) Extend beyond the dimensions of the section to distribute the load on the roof. (3) Be capable of adequately supporting the concentrated loads at the corners. These beams can usually be set directly on the roof. Flashing is not required.


**NOTE:** On bonded roofs, check for special installation requirements.

### **Ground Level Locations**

It is important that the units be installed on a substantial base that will not settle, causing strain on the refrigerant lines and possible leaks. A one-piece concrete slab with footers that extend below the frost line is recommended. The slab should not be tied to the building foundation, as noise will telegraph through the slab.

Size	Model	Weig	ht (Ibs.)	Center of (	Gravity (in.)	4 Point Load Location (lbs.)					
(Tons)	woder	Shipping	Operating	Х	Y	Α	В	С	D		
090	YC090	390	387	17	32.3	99	113	94	82		
(7.5)	YE090	386	383	18	33.5	95.0	124.3	92.8	70.9		
120	YC120	499	497	17.3	32.3	124	147	122	103		
(10)	YD120	493	490	17.4	32.5	123	147	120	100		
150	YC150	499	497	17	32.3	127	145	120	105		
(12.5)	YD150	493	490	17.4	32.5	123	147	120	100		
180	YC180	914	909	32.5	31.5	239	246	215	209		
(15)	YD180	903	898	32.5	31.5	236	243	213	207		
240	YC240	945	942	30.3	31.0	261	234	212	236		
(20)	YD240	930	927	32.7	31.8	244	255	218	210		
300 (25)	YC300	945	942	30.3	31.0	261	234	212	236		

#### Table 3: Corner Weights & Center of Gravity



#### Figure 1: Corner Weights & Center Of Gravity

**NOTE:** Front of unit is considered the side having the unit control box.

Concrete piers can also support ground level units. These piers should (1) extend below the frost line, (2) be located under each of the section's four corners, and (3) be sized to carry the load of the corner it supports.

On either rooftop or ground level installations, rubber padding can be applied under the unit to lessen any transmission of vibration.

For ground level installations, precautions should be taken to protect the unit from tampering and unauthorized persons from injury. Screws on access panels will prevent casual tampering. Further safety precautions such as a fenced enclosure or locking devices on the panels may be advisable. Check local authorities for safety regulations.

### Clearances

The unit must be installed with sufficient clearance for air to enter the condenser coil, for air discharge and for servicing access. See Table 4 for clearances.

**NOTE:** Additional clearance is required to remove the compressors out the back of the unit, unless a means is available to lift the compressor out through the top of the unit.

#### Table 4: Minimum Clearances

Clearance Description	Distance in Inches
Overhead (Top)	120
Front	36
Rear	24
Left Side	30
Right Side	30
Bottom <sup>1</sup>	0

 In all installations where snow accumulates and winter operation is expected, additional height must be provided to insure normal condenser airflow.

# **A**WARNING

Do not permit overhanging structures or shrubs to obstruct condenser air discharge.

### Rigging

Exercise care when moving the unit. Do not remove any packaging until the unit is near the place of installation. Rig the unit by attaching chain or cable slings to the lifting holes provided in the base rails. Spreader bars, whose length exceeds the largest dimension across the unit, **MUST** be used across the top of the unit.

The unit may be moved or lifted with a forklift. Slotted openings in the base rails are provided for this purpose.

### LENGTH OF FORKS MUST BE A MINIMUM OF 60 INCHES.

# A CAUTION

Spreaders, longer than the largest dimension across the unit must be used across the top of the unit.

# 

Before lifting a unit, make sure that its weight is distributed equally on the cables so that it will lift evenly.




Figure 2: Typical Rigging

### **Power Wiring**

Check the available power and the unit nameplate for correct voltage. Run the necessary number of properly sized wires to the unit. Provide a disconnect switch (if not included with the unit) and fusing as required (factory disconnect is a fused disconnect). Route the conduit through the large knockout located on the front of the electrical box. See Table 5 for Electrical Data.

The disconnect switch may be bolted to the side of the unit but not to any of the removable panels; this would interfere with access to the unit. Make sure that no refrigerant lines will be punctured when mounting the disconnect switch, and note that it must be suitable for outdoor installation.

## 

All power and control wiring must be in accordance with National and Local electrical codes.

### **Control Wiring**

Route the necessary low voltage control wires from the Smart Equipment<sup>™</sup> control board to the thermostat and also from the low voltage condenser unit control box to the terminal block inside the evaporator unit. See Figures 3 thru 11 for field wiring diagrams.

### Compressors

The scroll compressors used in this product are specifically designed to operate with R-410A Refrigerant and cannot be interchanged.

## **A** CAUTION

This system uses R-410A Refrigerant which operates at higher pressures than R-22. No other refrigerant may be used in this system.

The compressor also uses a polyolester (POE oil), Mobil 3MA POE. This oil is extremely hydroscopic, meaning it absorbs water readily. POE oil can absorb 15 times as much water as other oils designed for HCFC and CFC refrigerants. Take all necessary precautions to avoid exposure of the oil to the atmosphere.

## **A** CAUTION

Do not leave the system open to the atmosphere. Unit damage could occur due to moisture being absorbed by the **POE oil** in the system. This type of oil is highly susceptible to moisture absorption

POE (polyolester) compressor lubricants are known to cause long term damage to some synthetic roofing materials.

## **A** CAUTION

Exposure, even if immediately cleaned up, may cause embrittlement (leading to cracking) to occur in one year or more. When performing any service that may risk exposure of compressor oil to the roof, take precautions to protect roofing.

Procedures which risk oil leakage include, but are not limited to, compressor replacement, repairing refrigerant leaks, replacing refrigerant components such as filter drier, pressure switch, metering device or coil.

Units are shipped with compressor mountings which are factory adjusted and ready for operation.

## A CAUTION

Do not loosen compressor mounting bolts.

### Phasing

Three-phase, scroll compressors operate in only one direction. If the scroll is drawing low amperage, has similar suction and discharge pressures, or is producing a high noise level, the scroll is misphased. Change the incoming line connection phasing to obtain the proper rotation.

## **A** CAUTION

Scroll compressors require proper rotation to operate properly. Failure to check and correct rotation may result in property damage.

### **Electrical Data**

Table 5:	Electrical Data -	- Outdoor Unit -	AC Without Powered	<b>Convenience Outlet</b>
----------	-------------------	------------------	--------------------	---------------------------

Model			Outdoo	r Fan I	Notor		Pwr Conv Outlet	Minimum	Maximum			
	Power Supply	Qty	RLA (each)	MCC (each)	LRA (each)	Power Supply	HP	Qty	FLA (each)	FLA	Circuit Ampacity <sup>1</sup>	Fuse Size (A) <sup>2</sup>
	208/230-3-60	1	25.0	39	164	208/230-1-60	1/3	2	2.1	-	35.5	45
YC090	460-3-60	1	12.2	19	100	460-1-60	1/3	2	1.2	-	17.6	25
	575-3-60	1	9.0	14	78	575-1-60	1/3	2	0.9	-	13.1	20
	208/230-3-60	1	26.9	41.9	164	208/230-1-60	1/3	2	2.1	-	37.8	45
YE090	460-3-60	1	13.4	18.7	94	460-1-60	1/3	2	1.2	-	19.2	25
-	575-3-60	1	10	14	65	575-1-60	1/3	2	0.9	-	14.3	20
	208/230-3-60	2	15.7	24.5	110	208/230-1-60	3/4	2	3.0	-	41.4	50
YC120	460-3-60	2	7.8	12.0	52	460-1-60	3/4	2	1.6	-	20.8	25
	575-3-60	2	5.8	9.1	39	575-1-60	3/4	2	1.4	-	15.8	20
	208/230-3-60	2	16.0	25	110	208/230-1-60	3/4	2	3.0	-	42.1	50
YD120	460-3-60	2	7.8	12	52	460-1-60	3/4	2	1.6	-	20.8	25
	575-3-60	2	5.7	9	39	575-1-60	3/4	2	1.4	-	15.5	20
	208/230-3-60	2	22.4	35	149	208/230-1-60	3/4	2	3.0	-	56.5	70
YC150	460-3-60	2	10.6	17	75	460-1-60	3/4	2	1.6	-	27.1	35
	575-3-60	2	7.7	12	54	575-1-60	3/4	2	1.4	-	20.0	25
	208/230-3-60	2	22.4	35	149	208/230-1-60	3/4	2	3.0	-	56.5	70
YD150	460-3-60	2	10.6	17	75	460-1-60	3/4	2	1.6	-	27.1	35
	575-3-60	2	7.7	12	54	575-1-60	3/4	2	1.4	-	20.0	25
	208/230-3-60	2	25.0	39	164	208/230-1-60	1/3	4	2.1	-	64.7	80
YC180	460-3-60	2	12.2	19	100	460-1-60	1/3	4	1.2	-	32.2	40
	575-3-60	2	9.0	14	78	575-1-60	1/3	4	0.9	-	24.0	30
	208/230-3-60	2	25.0	39	164	208/230-1-60	3/4	4	3.0	-	68.4	90
YD180	460-3-60	2	12.2	19	100	460-1-60	3/4	4	1.6	-	33.9	45
	575-3-60	2	9.0	14	78	575-1-60	3/4	4	1.4	-	25.7	30
	208/230-3-60	2	30.1	47	225	208/230-1-60	3/4	4	3.0	-	79.8	100
YC240	460-3-60	2	16.7	26	114	460-1-60	3/4	4	1.6	-	44.0	60
	575-3-60	2	12.2	19	80	575-1-60	3/4	4	1.4	-	32.9	45
	208/230-3-60	2	30.1	47	225	208/230-1-60	3/4	4	3.0	-	79.8	100
YD240	460-3-60	2	16.7	26	114	460-1-60	3/4	4	1.6	-	44.0	60
	575-3-60	2	12.2	19	80	575-1-60	3/4	4	1.4	-	32.9	45
	208/230-3-60	2	48.1	75	245	208/230-1-60	3/4	4	3.0	-	120.3	150
YC300	460-3-60	2	18.6	29	125	460-1-60	3/4	4	1.6	-	48.3	60
	575-3-60	2	14.7	23	100	575-1-60	3/4	4	1.4	-	38.5	50

1. Based on three, 75°C insulated copper conductors in conduit and ambient of 30°C.

Maximum fuse or maximum circuit breaker (HACR type per NEC). Refer to NEC/NFPA No. 70, Articles 440-11, 12 for information on minimum disconnect sizing.

	Compressors				Outdoor Fan Motor				Pwr Conv Outlet	Minimum	Maximum	
Model	Power Supply	Qty	RLA (each)	MCC (each)	LRA (each)	Power Supply	HP	Qty	FLA (each)	FLA	Circuit Ampacity <sup>1</sup>	Fuse Size (A) <sup>2</sup>
	208/230-3-60	1	25.0	39	164	208/230-1-60	1/3	2	2.1	10.0	45.5	60
YC090	460-3-60	1	12.2	19	100	460-1-60	1/3	2	1.2	5.0	22.6	30
	575-3-60	1	9.0	14	78	575-1-60	1/3	2	0.9	4.0	17.1	25
	208/230-3-60	1	26.9	41.9	164	208/230-1-60	1/3	2	2.1	-	47.8	60
YE090	460-3-60	1	13.4	18.7	94	460-1-60	1/3	2	1.2	-	24.2	30
	575-3-60	1	10	14	65	575-1-60	1/3	2	0.9	-	18.3	25
	208/230-3-60	2	15.7	24.5	110	208/230-1-60	3/4	2	3.0	10.0	51.4	60
YC120	460-3-60	2	7.8	12.0	52	460-1-60	3/4	2	1.6	5.0	25.8	30
	575-3-60	2	5.8	9.1	39	575-1-60	3/4	2	1.4	4.0	19.8	25
	208/230-3-60	2	16.0	25	110	208/230-1-60	3/4	2	3.0	10.0	52.1	60
YD120	460-3-60	2	7.8	12	52	460-1-60	3/4	2	1.6	5.0	25.8	30
	575-3-60	2	5.7	9	39	575-1-60	3/4	2	1.4	4.0	19.5	25
	208/230-3-60	2	22.4	35	149	208/230-1-60	3/4	2	3.0	10.0	66.5	80
YC150	460-3-60	2	10.6	17	75	460-1-60	3/4	2	1.6	5.0	32.1	40
	575-3-60	2	7.7	12	54	575-1-60	3/4	2	1.4	4.0	24.0	30
	208/230-3-60	2	23.1	36	160	208/230-1-60	3/4	2	3.0	10.0	68.0	90
YD150	460-3-60	2	12.2	19	87	460-1-60	3/4	2	1.6	5.0	35.7	45
	575-3-60	2	8.7	14	62	575-1-60	3/4	2	1.4	4.0	26.3	30
	208/230-3-60	2	25.0	39	164	208/230-1-60	1/3	4	2.1	10.0	74.7	90
YC180	460-3-60	2	12.2	19	100	460-1-60	1/3	4	1.2	5.0	37.2	45
	575-3-60	2	9.0	14	78	575-1-60	1/3	4	0.9	4.0	28.0	35
	208/230-3-60	2	25.0	39	164	208/230-1-60	3/4	4	3.0	10.0	78.4	100
YD180	460-3-60	2	12.2	19	100	460-1-60	3/4	4	1.6	5.0	38.9	50
	575-3-60	2	9.0	14	78	575-1-60	3/4	4	1.4	4.0	29.7	35
	208/230-3-60	2	30.1	47	225	208/230-1-60	3/4	4	3.0	10.0	89.8	110
YC240	460-3-60	2	16.7	26	114	460-1-60	3/4	4	1.6	5.0	49.0	60
	575-3-60	2	12.2	19	80	575-1-60	3/4	4	1.4	4.0	36.9	45
	208/230-3-60	2	30.1	47	225	208/230-1-60	3/4	4	3.0	10.0	89.8	110
YD240	460-3-60	2	16.7	26	114	460-1-60	3/4	4	1.6	5.0	49.0	60
	575-3-60	2	12.2	19	80	575-1-60	3/4	4	1.4	4.0	36.9	45
	208/230-3-60	2	48.1	75	245	208/230-1-60	3/4	4	3.0	10.0	130.3	175
YC300	460-3-60	2	18.6	29	125	460-1-60	3/4	4	1.6	5.0	53.3	70
	575-3-60	2	14.7	23	100	575-1-60	3/4	4	1.4	4.0	42.5	50

#### Table 6: Electrical Data - Outdoor Unit - AC With Powered Convenience Outlet

1. Based on three, 75°C insulated copper conductors in conduit and ambient of 30°C.

Maximum fuse or maximum circuit breaker (HACR type per NEC). Refer to NEC/NFPA No. 70, Articles 440-11, 12 for information on minimum disconnect sizing.

### **Refrigerant Mains**

# **A** CAUTION

This Split-System (Air Condensing / Heat Pump / Air Handling) unit is one component of an entire system. As such it requires specific application considerations with regard to the rest of the system (air handling unit, duct design, condensing unit, refrigerant piping and control scheme).

Failure to properly apply this equipment with the rest of the system may result in premature failure and/or reduced performance / increased costs. Warranty coverage specifically excludes failures due to improper application and Ducted Systems specifically disclaims any liability resulting from improper application.

Please refer to the equipment Technical Guide, Installation Manual and the piping applications bulletin 247077 or call the applications department for Ducted Systems @ 1-877-874-SERV for guidance.

### Line Sizing

When sizing refrigerant pipe for a split-system air conditioner, check the following:

- 1. Suction line pressure drop due to friction.
- 2. Liquid line pressure drop due to friction.
- 3. Suction line velocity for oil return.
- Liquid line pressure drop due to vertical rise. For certain piping arrangements, different sizes of suction line pipe may have to be used. The velocity of the refrigerant vapor must always be great enough to carry the oil back to the compressor.
- 5. Evaporator Located Below Condenser On a split system where the evaporator blower is located below the condenser, the suction line must be sized for both pressure drop and for oil return.
- 6. Condenser Located Below Evaporator When the condenser is located below the evaporator blower, the liquid line must be designed for the pressure drop due to both friction loss and vertical rise. If the pressure drop due to vertical rise and friction exceeds 60 psi, some refrigerant will flash before it reaches the thermal expansion valve.

#### Flash gas:

- 1. Increases the liquid line pressure loss due to friction that in turn causes further flashing.
- Reduces the capacity of the refrigerant control device which starves the evaporator.
- 3. Erodes the seat of the refrigerant control device.
- 4. Causes erratic control of the refrigerant entering the evaporator.

#### **Take Adequate Precautions**

Many service problems can be avoided by taking adequate precautions to provide an internally clean and dry system and by using procedures and materials that conform to established standards.

Use hard drawn copper tubing where no appreciable amount of bending around pipes or other obstructions is necessary. If soft copper is used, care should be taken to avoid sharp bends that may cause a restriction. Pack fiberglass insulation and a sealing material such as permagum around refrigerant lines where they penetrate a wall to reduce vibrations and to retain some flexibility.

Support all tubing at minimum intervals with suitable hangers, brackets or clamps.

Braze all copper-to-copper joints with Silfos-5 or equivalent brazing material. Do not use soft solder. Insulate all suction lines with a minimum of 1/2" ARMAFLEX or equivalent that meets local codes. Liquid lines exposed to direct sunlight and/ or high temperatures must also be insulated. Never solder suction and liquid lines together. They can be taped together for convenience and support purposes, but they must be completely insulated from each other.

The liquid and suction service ports on the condenser section permit leak testing, evacuation, and partial charging of the field piping and the evaporator without disturbing refrigerant stored in the condenser during initial installation.

Before beginning installation of the main lines, be sure that the evaporator section has not developed a leak in transit. Check pressure at the Schrader valve located on the header of each coil. If pressure still exists in the system, it can be assumed to be leak free. If pressure DOES NOT exist the section will need to be repaired before evacuation and charging is performed.

A filter-drier MUST be field-installed in the liquid line of every system to prevent dirt and moisture from damaging the system. Properly sized filter-driers are shipped with each condensing section.

**NOTE:** Installing a filter-drier does not eliminate the need for the proper evacuation of a system before it is charged.

A field-installed moisture indicating sight-glass should be installed in the liquid line(s) between the filter-drier and the evaporator coil. The moisture indicating sight-glass can be used to check for excess moisture in the system.

Both condenser and evaporator sections have copper sealing disks brazed over the end of liquid and suction connections. The temperature required to make or break a brazed joint is high enough to cause oxidation of the copper unless an inert atmosphere is provided.

**NOTE:** Dry nitrogen should flow through the system at all times when heat is being applied and until the joint has

cooled. The flow of nitrogen will prevent oxidation of the copper lines during installation.

Always punch a small hole in sealing disks before unbrazing to prevent the pressure in the line from blowing them off. Do not use a drill as copper shavings can enter system.

- **NOTE:** Solenoid and hot gas bypass valves (if used) should be opened manually or electrically during brazing or evacuating.
- **NOTE:** Schrader valves located on unit service valves should have their stem removed during brazing to prevent damage to the valve.

### Start Installation

Start Installation of main lines at the condenser unit. Verify the service valves are fully seated by screwing the stem of both valves down into the valve body until it stops. Remove the Schrader valve stem and connect a low-pressure nitrogen source to the service port on the suction line valve body. Punch a small hole in the sealing disk; the flow of nitrogen will prevent any debris from entering the system. Wrap the valve body with a wet rag to prevent overheating during the brazing process. Overheating the valve will damage the valve seals. Unbraze the sealing disk, cool the valve body and prepare the joint for connections of the main lines. Repeat for the liquid line valve body.

## 

Never remove a cap from an access port unless the valve is fully back-seated with its valve stem in the maximum counter-clockwise position because the refrigerant charge will be lost. Always use a refrigeration valve wrench to open and close these service valves.

Connect the main liquid line to the liquid line service valve on the condenser section, while maintaining a flow of nitrogen. Cool the valve body and replace the Schrader valve stem on the service port of the liquid line service valve.

Install the liquid line from the condenser unit to the evaporator liquid connection, maintaining a flow of nitrogen during all brazing operations.

The filter-drier and sight glass must be located in this line, leaving the O.D. unit.

Connect a low-pressure nitrogen source to the Schrader valve located on the evaporator unit coil headers. Punch a small hole in the sealing disks, the flow of nitrogen will prevent any debris from entering the system. Unbraze both liquid and suction sealing disks and prepare the joints for connections of the main lines.

Connect the main liquid line to the liquid line connection on the evaporator unit, while maintaining a flow of nitrogen.

Make the suction line connection at the evaporator and run the line to the condenser unit. Connect the main suction line to the

suction line service line on the condenser unit, while maintaining a flow of nitrogen. Cool the valve body and replace the Schrader valve stem on the service port of the suction line service valve.

Once the brazing process is complete, leak testing should be done on all interconnecting piping and the evaporator before proper evacuation to 500 microns is performed. Once the line set and evaporator unit is properly evacuated the service valves can be opened and the condenser unit is now ready to charge with the appropriate weight of refrigerant.

Calculate the correct system charge for the condenser unit, the evaporator unit and the field line set. Charge the system by introducing liquid refrigerant into the liquid line through the liquid port connection. Complete adding the refrigerant in vapor form into the suction port when the compressor is started.

The correct refrigerant pressures are indicated as shown in Figures 16 through 25.

# 

After initial system startup, running both compressors for fifteen (15) minutes minimum, shut down the system and visually check the oil levels at both tandem compressor sight glasses. It is normal for one compressor oil level to be slightly lower than the other, as long as the oil levels are at the center (or lower third) of the sight glass.

If oil level is below one third of the sight glass, oil must be added. Use POE 32VIS oil or equivalent pumped into the low pressure suction port only.


## **A** CAUTION

This system uses R-410A Refrigerant which operates at higher pressures than R-22. No other refrigerant may be used in this system. Gage sets, hoses, refrigerant containers and recovery systems must be designed to handle R-410A. If you are unsure, consult the equipment manufacturer. Failure to use R-410A compatible servicing equipment may result in property damage or injury.

## 

Wear safety glasses and gloves when handling refrigerants. Failure to follow this warning can cause serious personal injury.

**NOTE:** This instruction covers the installation and operation of the basic condenser unit. For refrigerant piping installation instructions refer to document 247077 "Application Data - General Piping Recommendations for Split System Air Conditioning and Heat Pumps".



## **EVAPORATOR CONTROL BOX**

Figure 3: Typical Simplified Field Wiring Diagram – NC180 thru 240 Evaporator with YC150 thru 240 Condenser

**NOTE:** On non NC/ND (Third party) evaporator models, isolation relays must be installed to avoid overloading on 75 VA transformers on the condensing unit.






Figure 4: Typical NC120 - 240 Liquid Line Solenoid Wiring



## **EVAPORATOR CONTROL BOX**



**NOTE:** On non NC/ND (Third party) evaporator models, isolation relays must be installed to avoid overloading on 75 VA transformers on the condensing unit.






Figure 6: Typical NC300 Liquid Line Solenoid Wiring



## **EVAPORATOR CONTROL BOX**



**NOTE:** On non NC/ND (Third party) evaporator models, isolation relays must be installed to avoid overloading on 75 VA transformers on the condensing unit.






Figure 8: Typical Simplified Field Wiring Diagram – NL090 Evaporator with YC090/YE090 Condenser



## **EVAPORATOR CONTROL BOX**

- Figure 9: Typical Simplified Field Wiring Diagram NL120 thru 240 Evaporator with YC120 thru 240 Condenser
- **NOTE:** On non NL/NM (Third Party) evaporator models, isolation relays must be installed to avoid overloading on 75 VA transformers on the condensing unit.









Figure 11: Typical Simplified Field Wiring Diagram – NM120 thru 240 Evaporator with YD120 thru 240 Condenser

**NOTE:** On non NL/NM (Third Party) evaporator models, isolation relays must be installed to avoid overloading on 75 VA transformers on the condensing unit.




### Figure 12: YC090, YE090, YC/YD120, YC/YD150 Unit Dimensions

NOTE: Use a System 1 piping dimensions when applying a YC090/120/150 or YE090 model system.

Table 7: YC090, YE090, YC/YD120, YC/YD150 Unit Height Dimensions

MODEL	A
YC090	44.5
YE090	44.5
YC120	50.0
YD120	50.0
YC150	50.0
YD150	50.0



### Figure 13: YC/YD180, YC/YD240 & YC300 Unit Dimensions and Piping & Electrical Dimensions

NOTE: Use System 1 piping dimensions when applying a YC180/240/300 model system.

Table 8: YC/YD180, YC/YD240 and YC300 Unit Height Dimensions

MODEL	A
YC180	44.5
YD180	44.5
YC240	50.0
YD240	50.0
YC300	50.0

Table 9: Piping And Electrical Connection Sizes (Inches)

MODEL	YC090	YE090	YC120	YD120	YC150	YD150
No. Refrigeration Circuits	1	1	1	2	1	2
Suction Line OD (in.)	1 1/8	1 1/8	1 3/8	1 1/8	1 3/8	1 1/8
Liquid Line OD (in.)	5/8	5/8	7/8	5/8	7/8	5/8
Power Wiring Knockout	1 3/8	1 3/8	1 3/8	1 3/8	1 3/8	1 3/8
Control Wiring Knockout	7/8	7/8	7/8	7/8	7/8	7/8

MODEL	YC180	YD180	YC240	YD240	YC300
No. Refrigeration Circuits	1	2	1	2	1
Suction Line OD (in.)	1 5/8	1 1/8	1 5/8	1 3/8	1 5/8
Liquid Line OD (in.)	7/8	5/8	7/8	5/8	7/8
Power Wiring Knockout	1 3/8	1 3/8	1 3/8	1 3/8	1 3/8
Control Wiring Knockout	7/8	7/8	7/8	7/8	7/8

### **Piping And Electrical Connections**

Piping connections are made from the rear of 7.5 thru 12.5 Ton units and the front of 15 thru 25 Ton units. Connections can be made directly to the suction and liquid line service valves. Piping can be routed to the units from the left or right side.

Electrical connections for power and control wiring are made from the right or left side of all units. See Table 9 and Figures 12 and 13 for piping sizes and electrical knockout details.

## Start-Up

### Crankcase Heater

The crankcase heater must be energized at least 8 hours before starting the compressor. To energize the crankcase heater, the main disconnect switch must be closed. During this 8 hour period, the system switch on the room thermostat must be "OFF" to prevent the compressor from starting. Make sure that the bottom of the compressor is warm to the touch to prove crankcase heater operation.

# **A** CAUTION

Do not attempt to start the compressor without at least 8 hours of crankcase heat or compressor damage can occur.

### **Pre-Start Check**

Before starting the unit, complete the following check list:

- 1. Have sufficient clearances been provided?
- 2. Has all foreign matter been removed from the interior of the unit (tools, construction or shipping materials, etc.)?
- 3. Have the condenser fans been rotated manually to check for free rotation?
- 4. Are all wiring connections tight?
- 5. Does the available power supply agree with the nameplate data on the unit?
- 6. Is the control circuit transformer set for the proper voltage?
- 7. Have the fuses, disconnect switch and power wire been sized properly?
- 8. Are all compressor hold-down nuts properly secured?
- Are any refrigerant lines touching each other or any sheet metal surface? Rubbing due to vibration could cause a refrigerant leak.
- 10. Are there any visible signs of a refrigerant leak, such as oil residue?
- 11. Has the refrigeration system been leak checked, evacuated and had the correctly calculated charge weighted in?
- 12. Is any electrical wire laying against a hot refrigerant line?

### **Initial Start-Up**

1. Supply power to the unit through the disconnect switch at least 8 hours prior to starting the compressor.

- 2. Move the system switch on the thermostat to the AUTO or COOL position.
- 3. Reduce the setting of the room thermostat to energize the compressor.
- 4. Check the operation of the evaporator unit per the manufacturer's recommendations.
- 5. With an ammeter, check the compressor amps against the unit data plate.
- 6. Check for refrigerant leaks.
- Check for any abnormal noises and/or vibrations, and make the necessary adjustments to correct fan blade(s) touching shroud, refrigerant lines hitting on sheet metal, etc.
- After the unit has been operating for several minutes, shut off the main power supply at the disconnect switch and inspect all factory wiring connections and bolted surfaces for tightness.

## Operation

### **Unit Control Overview**

These series of condenser unit, come factory equipped with Smart Equipment<sup>™</sup> controls to monitor all unit functionality and safety controls.

### Safety Controls

The Smart Equipment<sup>™</sup> control board incorporates features to monitor safety circuits as well as minimize compressor wear and damage. An anti-short cycle delay (ASCD) is utilized to prevent operation of a compressor too soon after its previous run. Additionally, a minimum run time is imposed anytime a compressor is energized to allow proper oil return to the compressor. The ASCD is initiated on unit start-up and on any compressor reset or lockout.

The Smart Equipment<sup>™</sup> control board monitors the following inputs for each cooling system:

- A high-pressure switch is factory installed to protect against excessive discharge pressure due to a blocked condenser coil or a condenser fan motor failure. During cooling operation, if a high-pressure limit switch opens, the Smart Equipment<sup>™</sup> control board will de-energize the associated compressors and initiate the 5-minute ASCD. If the call for cool is still present at the end of the ASCD, the control board will re-energize the halted compressor. If a high-pressure switch opens three times within two hours of operation, the Smart Equipment<sup>™</sup> control board will lockout the associated system compressors and will deliver an error message on the LCD.
- A low-pressure switch to protect the unit against excessively low suction pressure is standard on all condensing units. If the low-pressure switch opens during normal operation, the Smart Equipment<sup>™</sup> control board will de-energize the compressor, initiate the ASCD, and

shut down the condenser fans. On startup, if the lowpressure switch opens, the Smart Equipment<sup>™</sup> control board will monitor the low-pressure switch to make sure it closes within one minute. If it fails to close, the unit will shut down the associated compressor and begin an ASCD. If the call for cool is still present at the end of the anti-short cycle time delay, the control board will reenergize the halted compressor. If a low-pressure switch opens three times within one hour of operation, the Smart Equipment<sup>™</sup> control board will lock-out the associated compressor and will deliver an error message on the LCD.

• An ambient air sensor will lock out mechanical cooling at 45°F. A factory equipped low ambient option allows the unit to operate down to 0°F. A field installed low ambient kit is also available.

The refrigerant systems are independently monitored and controlled. On any fault, only the associated system will be affected by any safety/preventive action. The other refrigerant system will continue to operate unless it is affected by the fault as well.

### **Sequence of Operation**

### **Continuous Blower**

By setting the room thermostat to "ON," the low voltage control circuit from the "R" to "G" is completed and the supply air blower will operate continuously.

### Intermittent Blower

With the room thermostat fan switch set to "AUTO" and the system switch set to either the "AUTO" or "HEAT" settings, the blower is energized whenever a cooling or heating operation is requested. The blower is energized after any specified delay associated with the operation.

When energized in cooling mode, the indoor blower has a minimum run time of 30 seconds. Additionally, the indoor blower has a delay of 10 seconds between operations.

### **Cooling Sequence Of Operation**

### Single-Stage Condensing Unit (YC090)

A single stage cooling thermostat is required to operate the condenser unit.

**NOTE:** Single-Stage Condensing Unit (YC090) matched with a Two Speed Air Handling Unit (NL090) requires a two stage cooling thermostat.

When the thermostat calls for cooling (Y1), UCB closes the coils of relay RY1 and contactors M1 and M3.

- Relay RY1 controls the crankcase heater (CCH1). The normally closed contacts allow CCH1 to operate during unit shutdown.
- · Contactor M1 controls compressor COMPR1.
- Contactor M3 controls outdoor fans ODFAN1 & 2.

After completing the specified time for fan on-delay, UCB closes the coil of relay BR1.

 Relay BR1 sends a 24V signal to G1 of terminal block TB2. It may be used to control operation of an indoor blower.

When the call for cooling (Y1) is satisfied, the UCB disables the signal to RY1, M1 and M3 as long as the specified minimum run time (ASCD) has elapsed.

The UCB disables the signal to BR1 after completing the fan off-delay period.

### Dual Stage Condensing Unit (YE090)

A two stage cooling thermostat is required to operate the condenser unit.

When the thermostat calls for first-stage cooling (Y1), the UCB closes the coils of Contactor M1 & M3 and relay BR1..

- Relay BR1 sends a 24V signal to G1 of terminal block TB2. It may be used to control operation of an indoor blower.
- Contactor M1 controls compressor COMPR1.
- Contactor M3 controls all outdoor fans.

When the thermostat calls for second-stage cooling (Y2), the UCB closes the coils of the compressor solenoid.

· Contactor M2 controls compressor COMPR2.

If the initial call for cooling requires both stages (Y1 and Y2), the UCB will delay the second stage by 30 seconds to avoid an excessive power inrush.

When the call for cooling (Y2) is satisfied, the UCB disables the signal to Compressor solenoid coil as long as the specified minimum run time (ASCD) has elapsed.

When the call for cooling (Y1) is satisfied, the UCB disables the signal to M1 & BR1 as long as the specified minimum run time (ASCD) has elapsed.

### Dual Stage Condenser Unit (YC120-300 or YD120-150)

A two stage cooling thermostat is required to operate the condenser unit.

- When the thermostat calls for first-stage cooling (Y1), the UCB closes the coils of relays RY1 and BR1 and contactor M1.
- Relay RY1 has three functions. 1) control the crankcase heater CCH1. 2) control the coil of contactor M3. 3) control the 24V output signal to S1 on terminal block TB2.
- Relay BR1 sends a 24V signal to G1 of terminal block TB2. It may be used to control operation of an indoor blower.
- · Contactor M1 controls compressor COMPR1.
- · Contactor M3 controls all outdoor fans.

When the thermostat calls for second-stage cooling (Y2), the UCB closes the coils of relays RY2 and contactor M2.

- Relay RY2 has three functions. 1) control the crankcase heater CCH2. 2) control the coil of contactor M3. 3) control the 24V output signal to S2 on terminal block TB2.
- · Contactor M2 controls compressor COMPR2.

If the initial call for cooling requires both stages (Y1 and Y2), the UCB will delay the second stage by 30 seconds to avoid an excessive power inrush.

When the call for cooling (Y2) is satisfied, the UCB disables the signal to RY2 and M2 as long as the specified minimum run time (ASCD) has elapsed.

When the call for cooling (Y1) is satisfied, the UCB disables the signal to RY1, BR1 and M1 as long as the specified minimum run time (ASCD) has elapsed.

### Dual Stage Condenser Unit (YD180-240)

A two stage cooling thermostat is required to operate the condenser unit.

When the thermostat calls for first-stage cooling (Y1), the UCB closes the coils of relays RY1 and BR1 and contactor M1.

- Relay RY1 has three functions. 1) control the crankcase heater CCH1. 2) control the coil of contactor M3. 3) control the 24V output signal to S1 on terminal block TB2.
- Relay BR1 sends a 24V signal to G1 of terminal block TB2. It may be used to control operation of an indoor blower.
- · Contactor M1 controls compressor COMPR1.
- Contactor M3 controls outdoor fans ODFAN 1 & 2.

When the thermostat calls for second-stage cooling (Y2), the UCB closes the coils of relays RY2 and contactor M2.

- Relay RY2 has three functions. 1) control the crankcase heater CCH2. 2) control the coil of contactor M4. 3) control the 24V output signal to S2 on terminal block TB2.
- · Contactor M2 controls compressor COMPR2.
- Contactor M4 controls outdoor fans ODFAN 3 & 4.

If the initial call for cooling requires both stages (Y1 and Y2), the UCB will delay the second stage by 30 seconds to avoid an excessive power inrush.

When the call for cooling (Y2) is satisfied, the UCB disables the signal to RY2 and M2 as long as the specified minimum run time (ASCD) has elapsed.

When the call for cooling (Y1) is satisfied, the UCB disables the signal to RY1, BR1 and M1 as long as the specified minimum run time (ASCD) has elapsed.

### Low Ambient Cooling

These units are factory equipped with Outdoor Air Temperature Sensors (OAT) that work through the Smart Equipment<sup>™</sup>

control board to operate the compressors and condenser fans normally to 45°F ambient temperature. The Electronic Low Ambient Controller 2LA04703\*\*\*\* Accessory is designed to assure safe operation through condenser head pressure regulation down to 0°F ambient temperature.

Low Ambient Control Operation

 A call for cooling closes contactor M3 which energizes all condenser fans on all models except YD180-240. Both M3 & M4 control fans on YD180-240. The Low Ambient Control starts all fans at full speed then adjusts according to the liquid line temperature.

Refer to the appropriate 2LA low ambient kit instructions for additional detail on the factory or field installed low ambient kit and its operation.




Figure 14: Fan Orientation - Control Box End

## **Control Board Navigation Components**

The following components are needed to access the control points in the Smart Equipment<sup>™</sup> control. Installation and operation guides are available from your equipment dealer or distributor.

- 1. Local LCD on Unit Control Board.
- 2. Mobile Access Portal (MAP) Gateway (Portable).
  - Source 1 P/N S1-JC-MAP1810-OP
- 3. MAP Gateway Quick Start Guide P/N 24-10737-16
- 4. MAP Gateway Instruction P/N 24-10737-8

For more information on the Smart Equipment<sup>™</sup> unit control board navigation, refer to the *Smart Equipment<sup>™</sup> Quick Start Guide*.

NOTE: For more in-depth sequence of operation of the Smart Equipment<sup>™</sup> control, refer to the Smart Equipment<sup>™</sup> Controls Sequence of Operation Overview LIT-12011950.



WIRED HERE

### Figure 15: Unit Control Board

	Description	Function & Comments					
	Terminal Directional orientation: viewed with silkscreen labels upright Limit, 24 VAC power and shutdown connections from unit wiring harness at left on upper edge of UCB						
Limit, 24							
LIMIT	Monitored 24 VAC input through heat section limit switch(es)	If voltage is absent, indicating the heat section is over- temperature, the UCB will bring on the indoor blower					
С	24 VAC, 75 VA transformer Common referenced to cabinet ground	Connects through circuit traces to thermostat connection strip C and indoor blower VFD pin C					
24V	24 VAC, 75 VA transformer hot	Powers the UCB microprocessor, connects through circuit trace to the SD 24 terminal					
SD 24	24 VAC hot out for factory accessory smoke detector, condensate overflow and/or user shutdown relay switching in series	Connects through circuit trace to thermostat connection strip SD-24. A wiring harness jumper plug connecting SD 24 to SD R is in place if factory accessories for unit shutdown are not used - this jumper plug must be removed if the switching of field-added external accessories for unit shutdown are wired between thermostat connection strip SD-24 and R					
SD R	24 VAC hot return from factory accessory smoke detector, condensate overflow and user shutdown relay switching in series	Connects through circuit trace to the R terminal on the upper left of the board					
R	24 VAC hot for switched inputs to the UCB	Connects through circuit trace to the thermostat connection strip R terminal, right FAN OVR pin, right HPS1 pin, right HPS2 pin, lower DFS pin and lower APS pin					

	Description	Function & Comments		
	Terminal Thermostat connection strip	o on left edge of UCB		
W1	1st stage heating request, 24 VAC input switched from R	Not effective for cooling-only units		
W2	2nd stage heating request, 24 VAC input switched from R	Not effective for cooling-only units or units with single-stage heat sections		
Y1	1st stage cooling request, 24 VAC input switched from R			
Y2	2nd stage cooling request, 24 VAC input switched from R	Visible in the display menu when the #ClgStgs parameter is set for 2 or more, also effective for economizer free cooling supply air temperature reset when the #ClgStgs parameter is set for 1 or more		
G	Continuous indoor blower request, 24 VAC input switched from R			
000	Occupancy request, 24 VAC input switched from R	Must have the OccMode parameter set for External to be effective		
x	Hard lockout indicator, 24 volt output to a light thermostat LED			
R	24 VAC hot for thermostat switching and power	If field-added external accessories for unit shutdown are used, 24 VAC hot return from smoke detector, condensate overflow and/or user shutdown relay switching in series		
SD-24	If field-added external accessories for unit shutdown are used, 24 VAC hot out for smoke detector, condensate over- flow and/or user shutdown relay switching in series	Unit wiring harness jumper plug for factory shutdown accessories must be removed if the switching of field-added external accessories for unit shutdown are wired between thermo- stat connection strip SD-24 and R		
С	24 VAC common for thermostat power			
	LEDs on left edge of	UCB		
POWER	Green UCB power indicator	Lit indicates 24 VAC is present at C and 24V terminals		
FAULT	Red hard lockout, networking error and firmware error indicator	1/2 second on/off flashing indicates one or more alarm is currently active, 1/10th second on/off flashing indicates a networking error (polarity, addressing, etc.) or a firmware error (likely correctable with re-loading from USB flash drive)		
SA BUS	Green UCB SA bus communication transmission indicator	Lit/flickering indicates UCB SA bus communication is currently active, off indicates the UCB is awaiting SA bus communication		
	Terminal Space temperature sensor connections	at center on upper edge of UCB		
ST	Space Temperature sensor input from 10KΩ @ 77°F, Type III negative temperature coefficient thermistor	Positive of VDC circuit (3.625 VDC reading to COM with open circuit), effective if "Thermo- stat-only Control" parameter is set OFF, space sensor override momentary shorts ST to COM to initiate/terminate temporary occupancy		
СОМ	Common for ST and SSO inputs	Negative of VDC circuit for ST and SSO inputs		
SSO	Space Sensor Offset input from 0 to $20K\Omega$ potentiometer	Positive of VDC circuit (3.625 VDC reading to COM with open circuit), $10K\Omega/2.5$ VDC is 0°F offset, $0\Omega/0$ VDC is maximum above offset and $20K\Omega/3.4$ VDC is maximum below offset from active space temperature setpoint		
	Pin Temperature sensor connections at rig	ght on upper edge of UCB		
SAT+	Supply Air Temperature sensor input from 10KΩ @ 77°F, Type III negative temperature coefficient thermistor	Input required for operation; 3.625 VDC reading SAT+ to SAT- with open circuit. Used in heat/cool staging cutouts, free cooling operation, demand ventilation operation, comfort ventilation operation, economizer loading operation, VAV cooling operation, hydronic heat operation.		

	Description	Function & Comments
RAT+	Return Air Temperature sensor input from $10K\Omega$ @ $77^{\circ}F$ , Type III negative temperature coefficient thermistor	Input required for operation; 3.625 VDC reading RAT+ to RAT– with open circuit. Used in return air enthalpy calculation. Substitutes for space temperature if no other space temperature input is present.
OAT+	Outside Air Temperature sensor input from 10KΩ @ 77°F, Type III negative temperature coefficient thermistor	Input required for operation but may be a communicated value; 3.625 VDC reading OAT+ to OAT– with open circuit. Used in heat/cool cutouts, low ambient cooling determination, dry bulb free cooling changeover, outside air enthalpy calculation, economizer loading operation, heat pump demand defrost calculation.
CC1+	#1 refrigerant circuit Condenser Coil temperature sensor input from $10K\Omega @ 77^{\circ}F$ , Type III negative temperature coefficient thermistor	Input required for heat pump units, not required for A/C units; 3.625 VDC reading CC1+ to CC1– with open circuit. Used in heat pump demand defrost calculation.
EC1+	#1 refrigerant circuit Evaporator Coil/Suction line temperature sensor input from 10KΩ @ 77°F, Type III negative temperature coefficient thermistor	Input required for operation; 3.625 VDC reading EC1+ to EC1– with open circuit. Used in suction line temperature safety.
CC2+	#2 refrigerant circuit Condenser Coil temperature sensor input from $10K\Omega @ 77^{\circ}F$ , Type III negative temperature coefficient thermistor	Input required for 2-compressor heat pump units, not required for 2-compressor A/C units, not active for 1-compressor units; 3.625 VDC reading CC2+ to CC2- with open circuit. Used in heat pump demand defrost calculation.
EC2+	<ul> <li>#2 refrigerant circuit Evaporator Coil/Suction line temperature sensor input from 10KΩ @ 77°F, Type III negative temperature coefficient thermistor</li> </ul>	Input required for operation of 2-compressor units, not active for 1-compressor units; 3.625 VDC reading EC2+ to EC2– with open circuit. Used in suction line temperature safety.
	Pinned connections on right	edge of UCB
RAH+	Return Air Humidity input from 0-10 VDC @ 0- 100% RH sensor	Input required for reheat units, optional in all other units, may be a communicated value. Used in return air enthalpy calculation, temperature/humidity setpoint reset, reheat operation.
DCT PRS+	Supply Duct Pressure input from 0-5 VDC @ 0-5" w.c. sensor	Input required for variable air volume units. Used in VAV indoor blower operation.
DFS (upper pin)	24 VAC hot return from Dirty Filter Switch	Optional input; switch closure for greater than 15 seconds during indoor blower operation initiates a notification alarm
DFS (lower pin)	24 VAC hot out for Dirty Filter Switch	Connects through circuit trace to the R terminal
APS (upper pin)	24 VAC hot return from Air Proving Switch	When this optional input is enabled: the air proving switch must close within 30 seconds of initiation of indoor blower operation and not open for greater than 10 seconds during indoor blower operation to allow heat/cool operation and prevent an "APS open" alarm; the air proving switch must open within 30 seconds of termination of indoor blower operation to prevent an "APS stuck closed" notification alarm
APS (lower pin)	24 VAC hot out for Air Proving Switch	Connects through circuit trace to the R terminal
С	Common for the VFD output	Negative of the VDC circuit for the VFD output
VFD	2-10 VDC (0-100%) output for the indoor blower Variable Frequency Drive	Output is active with indoor blower operation. For CV units: this output provides stepped IntelliSpeed control of the indoor blower VFD based on fan-only, cooling stage and heating stage outputs. For VAV units: this output provides control of the indoor blower VFD based on supply duct static pressure input and setpoint.
VFDFLT	24 VAC hot input from the normally open VFD alarm contact	The VFD alarm contact switches from R within the unit wiring harness. 24 VAC input results in unit shutdown and a "VFD fault" alarm

	Description	Function & Comments
	Terminal at lower right cor	ner of UCB
24V FOR OUTPUTS	24 VAC hot for H1, H2, CN-FAN, AUX HGR, FAN C1 and C2 output relay contact switching	Output relay circuitry is isolated from other UCB components and the 24 VAC hot source may be from a second transformer in the unit
	Pin Heat section connections at right	on lower edge of UCB
H1	24 VAC hot output for heat section stage 1	Not effective for cooling-only units. Output if demand is present and permissions allow one stage or two stages of heat section operation
H2	24 VAC hot output for heat section stage 2	Not effective for cooling-only units or units with single-stage heat sections. Output if demand is present and permissions allow two stages of heat section operation
MV	24 VAC hot input confirming heat section operation	Sourced from gas valve in gas heat units or first stage heat contactor in electric heat units. Input within 5 minutes from initiation of H1 output initiates the "Heat On Fan Delay" timer, loss of input following the termination of H1 output initiates the "Heat On Fan Delay" timer, no input within 5 minutes from initiation of H1 output initiates an "Ignition Failure" alarm, input for longer than 5 minutes without H1 output initiates a "Gas Valve Mis-wire" alarm
	Pin Cooling and fan output connections at	right on lower edge of UCB
CN-FAN	24 VAC hot output for the condenser fan contactor coil	Output with either C1 or C2 output; interrupted during defrost cycle for heat pump units
AUX HGR	24 VAC hot output for hot gas reheat components	Effective only for reheat units, output with reheat operation
FAN	24 VAC hot output for indoor blower contactor coil/ indoor blower VFD enable relay coil	Output with heat/cool operation, G input or schedule demand
C1	24 VAC hot output for compressor 1	If demand is present and permissions allow compressor 1 operation; output with compressor cooling, comfort ventilation cooling, reheat or heat pump heating demands
C2	24 VAC hot output for compressor 2	Not effective for one stage compressor UCBs. If demand is present and permissions allow compressor 2 operation; output with compressor cooling, comfort ventilation cooling or heat pump heating demands
Pin Refrigera	ant circuit safety switch and indoor blower overloa	d connections at center on lower edge of UCB
HPS1 (right pin)	24 VAC hot out for refrigerant circuit 1 High Pressure Switch	Connects through circuit trace to the R terminal
HPS1 (left pin)	24 VAC hot return from refrigerant circuit 1 High Pressure Switch	Input is only considered if C1 output is needed; input must be present to allow C1 output. Three HPS1 trips in a two hour period cause a "High Pressure Switch 1 Lockout" and C1 output is then prevented until alarm reset. Connects through circuit trace to the right LPS1 pin.
LPS1 (right pin)	24 VAC hot out for refrigerant circuit 1 Low Pressure Switch	Connects through circuit trace to the left HSP1 pin
LPS1 (left pin)	24 VAC hot return from refrigerant circuit 1 Low Pressure Switch	Input is only considered after 30 seconds of C1 output; afterwards, input must be present to allow C1 output. Three LPS1 trips in a one hour period cause a "Low Pressure Switch 1 Lockout" and C1 output is then prevented until alarm reset.
HPS2 (right pin)	24 VAC hot out for refrigerant circuit 2 High Pressure Switch	Not effective for one stage compressor UCBs. Connects through circuit trace to the R terminal

	Description	Function & Comments
HPS2 (left pin)	24 VAC hot return from refrigerant circuit 2 High Pressure Switch	Not effective for one stage compressor UCBs. Input is only considered if C2 output is needed; input must be present to allow C1 output. Three HPS2 trips in a two hour period cause a "High Pressure Switch 1 Lockout" and C2 output is then prevented until alarm reset. Connects through circuit trace to the right LPS2 pin.
LPS2 (right pin)	24 VAC hot out for refrigerant circuit 2 Low Pressure Switch	Not effective for one stage compressor UCBs. Connects through circuit trace to the left HSP2 pin
LPS2 (left pin)	24 VAC hot return from refrigerant circuit 2 Low Pressure Switch	Not effective for one stage compressor UCBs. Input is only considered after 30 seconds of C2 output; afterwards, input must be present to allow C2 output. Three LPS2 trips in a one hour period cause a "Low Pressure Switch 2 Lockout" and C2 output is then prevented until alarm reset.
FAN OVR (right pin)	24 VAC hot out for indoor blower FAN Overload relay contact/motor protector switch	Connects through circuit trace to the R terminal
FAN OVR (left pin)	24 VAC hot return from indoor blower FAN Overload relay contact/motor protector switch	Input is only considered if FAN output is needed; input must be present to allow FAN output and unit operation. One FAN OVR trip lasting longer than 5 minutes or three FAN OVR trips in a two hour period cause a "Fan Overload Lockout" and unit operation is then prevented until alarm reset.
	Terminal SA BUS <sup>1</sup> connections on at left on I	ower edge and center of UCB
PWR	Power for SA ("Sensor-Actuator") BUS devices	Also incorporated in the J8 6-pin phone jack connector at the left-center of the board. Positive of the 15 VDC (reading to C) circuit for powering an optional netstat and/or Multi Touch gateway
С	Common for SA BUS power and communication circuits	Also incorporated in the J8 6-pin phone jack connector at the left-center of the board. Negative of the SA BUS circuits
-	Communication for SA BUS devices	Also incorporated in the J8 6-pin phone jack connector at the left-center of the board. Positive of the VDC (typically, a fluctuating 1.5 to 3.5 volts reading to C; at least 0.25 volts lower than +) SA BUS communication circuit to optional economizer board, 4-stage board, fault detection & diagnostics board, netstat and/or Multi Touch gateway
÷	Communication for SA BUS devices	Also incorporated in the J8 6-pin phone jack connector at the left-center of the board. Positive of the VDC (typically, a fluctuating 1.5 to 3.5 volts reading to C; at least 0.25 volts higher than –) SA BUS communication circuit to optional economizer board, 4-stage board, fault detection & diagnostics board, netstat and/or Multi Touch gateway
J8	6-pin phone jack connector	Incorporates the SA BUS terminals for convenience/alternate connection of SA BUS devices, primarily used for temporary service connection of the Multi Touch gateway
	Item Integrated user interface at low	er left corner of UCB
Display	On-board, 2-line x 8-character back-lit display	On-board display, buttons and joystick allow access to UCB, economizer, 4-stage and FDD board parameters
ENTER	Button for display menu acknowledgment and navigation	
CANCEL	Button for display menu navigation and zeroing of active compressor ASCD timer	
JOY	4-way Joystick for display menu navigation	
	Item USB connector at rig	ht of UCB
J10	Type A female Universal Serial Bus connector	Used for backup, restoration, & copying of board parameters as well as board software updating through a flash drive

	Description	Function & Comments
J15	Factory wired SA Bus connector	
	Optional communication sub-bo	ard at center of UCB
	Terminal FC BUS <sup>1</sup> connections on left edg	e of the communication board
FC+	FC ("Field Connected") BUS BACnet MSTP communication	Positive of the VDC (typically, a fluctuating 1.5 to 3.5 volts reading to COM; at least 0.25 volts higher than –) FC bus BACnet MSTP communication circuit
FC-	FC ("Field Connected") BUS BACnet MSTP communication	Positive of the VDC (typically, a fluctuating 1.5 to 3.5 volts reading to COM; at least 0.25 volts lower than +) FC bus BACnet MSTP communication circuit
СОМ	Common for the FC ("Field Connected") BUS BACnet MSTP communication circuit	Negative of the VDC FC bus BACnet MSTP communication circuit
SHLD	Shield for the FC ("Field Connected") BUS BACnet MSTP communication circuit	Earth ground reference of the cable to prevent interference on the FC bus BACnet MSTP communication circuit
	Item Selector in red housing at left on top ed	ge of the communication board
EOL switch	End Of Line selector switch for the FC BUS BACnet MSTP communication circuit	ON selected only for the UCB that is the terminus of the FC bus BACnet MSTP communication cable to prevent signal "bounce back"
	LEDs on the communic	ation board
EOL	Green End Of Line indicator	Lit indicates the EOL switch is selected ON
FC BUS	Green FC bus communication transmission indicator	Lit/flickering indicates outgoing UCB FC bus communication is currently active, off indicates the UCB is awaiting incoming FC bus communication
ISO PWR	Green communication board Isolated Power indicator	Lit indicates the UCB is supplying power to the communication sub-board


1. When wiring unit and other devices using the SA Bus and FC Bus, see Table 11.

### Table 11: Cable for FC Buses and SA Buses in Order of Preference

Bus and Cable Type	Non-Plenum Applications		Plenum Applications	
	Part Number	0.D.	Part Number	0.D.
FC Bus: 22 AWG Stranded, 3-Wire Twisted Shielded Cable <sup>1</sup>	Anixter: CBL-22/3-FC-PVC Belden®: B5501FE	0.138 in.	Anixter: CBL-22/3-FC-PLN Belden: B6501FE	0.140 in.
<b>SA Bus (Terminal Block):</b> 22 AWG Stranded, 4-Wire, 2 Twisted-Pair Shielded Cable	Anixter: CBL-22/2P-SA-PVC Belden: B5541FE	0.209 in.	Anixter: CBL-22/2P-SA-PLN Belden: B6541FE	0.206 in.
SA Bus (Modular Jack): 26 AWG Solid 6-Wire, 3 Twisted-Pair Cable <sup>2</sup>	_	_	Anixter preassembled: CBL- NETWORK25 CBL- NETWORK50 CBL- NETWORK75 CBL- NETWORK100	0.15 in.
FC Bus: 22 AWG Stranded, 3-Wire Twisted Non-Shielded Cable	Belden: B5501UE	0.135 in.	Belden: B6501UE	0.131 in.
<b>SA Bus (Terminal Block):</b> 22 AWG Stranded, 4-Wire, 2 Twisted- Pair Non-Shielded Cable	Belden: B5541UE	0.206 in.	Belden: B6541UE	0.199 in.

We strongly recommend 3-wire (for FC bus) and 4-wire, 2 twisted-pair (for SA bus), 22 AWG stranded, shielded cable. A 22 gauge cable
offers the best performance for various baud rates, cable distances, and number of trunk devices primarily due to lower conductor-toconductor capacitance. Shielded cable offers better overall electrical noise immunity than non-shielded cable. Observe the shield
grounding requirements.

2. We recommend 26 AWG solid, 6-wire (3 twisted pairs) cable as the best fit for fabricating modular cables with the modular jack housing assembly. Be sure the cable you use fits the modular jack housing. The preassembled cables that are available from Anixter (Part No. CBL-NETWORKxxx) use 24 gauge wire.




### Charging Curves YC090/YE090

1. Make sure that both condenser fans are running when charging.

2. This chart is applicable to unit with the TXV's left to the factory setting. If the TXV's have been adjusted in the field, the charging chart may no longer apply.

Figure 16: YC090 and YE090 Charging Chart






1. Make sure that both condenser fans are running when charging.

2. This chart is applicable to unit with the TXV's left to the factory setting. If the TXV's have been adjusted in the field, the charging chart may no longer apply.

#### Figure 17: YC120 Charging Chart




Charging Curves YD180

1. Make sure that both condenser fans are running when charging. One set of fans may switch off at lower ambient temperatures making the chart above inaccurate.

2. This chart is applicable to unit with the TXV's left to the factory setting. If the TXV's have been adjusted in the field, the charging chart may no longer apply.


Figure 18: YD120 Charging Chart



1. Make sure that both condenser fans are running when charging.

2. This chart is applicable to unit with the TXV's left to the factory setting. If the TXV's have been adjusted in the field, the charging chart may no longer apply.

### Figure 19: YC150 Charging Chart




## Charging Curves YD150

1. Make sure that both condenser fans are running when charging.


This chart is applicable to unit with the TXV's left to the factory setting. If the TXV's have been adjusted in the field, the charging chart may no longer apply.

Figure 20: YD150 Charging Chart



- 1. Make sure that both condenser fans are running when charging.
- 2. This chart is applicable to unit with the TXV's left to the factory setting. If the TXV's have been adjusted in the field, the charging chart may no longer apply.

### Figure 21: YC180 Charging Chart




Charging Curves

1. Make sure that all condenser fans are running when charging.

2. This chart is applicable to unit with the TXV's left to the factory setting. If the TXV's have been adjusted in the field, the charging chart may no longer apply.

Figure 22: YD180 Charging Chart


## Charging Curves YC240



1. Make sure that all condenser fans are running when charging.

2. This chart is applicable to unit with the TXV's left to the factory setting. If the TXV's have been adjusted in the field, the charging chart may no longer apply.

Figure 23: YC240 Charging Chart




**Charging Curves** 

1. Make sure that all condenser fans are running when charging.

2. This chart is applicable to unit with the TXV's left to the factory setting. If the TXV's have been adjusted in the field, the charging chart may no longer apply.

Figure 24: YD240 Charging Chart



Charging Curves

1. Make sure that both condenser fans are running when charging.

2. This chart is applicable to unit with the TXV's left to the factory setting. If the TXV's have been adjusted in the field, the charging chart may no longer apply.

### Figure 25: YC300 Charging Chart

### **Typical Wiring Diagrams**




Figure 26: Typical YC090 Condensing Unit Wiring Diagram




Figure 27: Typical YE090 Condensing Unit Wiring Diagram




Figure 28: Typical YC120 - 150 Condensing Unit Wiring Diagram




Figure 29: Typical YD120 - 150 Condensing Unit Wiring Diagram




Figure 30: Typical YC180 Condensing Unit Wiring Diagram




Figure 31: Typical YC240 Wiring Diagram




Figure 32: Typical YC300 Wiring Diagram




Figure 33: Typical YD180 - 240 Wiring Diagram

# **START-UP & SERVICE DATA INSTRUCTION**

# **COMMERCIAL SPLIT SYSTEMS**

7.5 To 50.0 TON

# **START-UP CHECKLIST**

Date:	 		
Job Name:	 		
Customer Name:	 		
Address:	 		
City:			
Evaporator Model Number:	 Serial Number:		
Condenser Model Number:	 Serial Number:		
Qualified Start-up Technician:	 Signature:		
HVAC Contractor:	 	Phone:	
Address:	 		
Contractor's E-mail Address:	 		
Electrical Contractor:	 	Phone:	
Distributor Name:	 	Phone:	

# WARRANTY STATEMENT

Johnson Controls/Ducted Systems is confident that this equipment will operate to the owner's satisfaction if the proper procedures are followed and checks are made at initial start-up. This confidence is supported by the 30 day dealer protection coverage portion of our standard warranty policy which states that Johnson Controls/ Ducted Systems will cover parts and labor on new equipment start-up failures that are caused by a defect in factory workmanship or material, for a period of 30 days from installation. Refer to the current standard warranty policy and warranty manual for details.

In the event that communication with Johnson Controls/Ducted Systems is required regarding technical and/or warranty concerns, all parties to the discussion should have a copy of the equipment start-up sheet for reference. A copy of the original start-up sheet should be filed with the Technical Services Department.

The packaged unit is available in constant or variable air volume versions with a large variety of custom options and accessories available. Therefore, some variation in the startup procedure will exist depending upon the products capacity, control system, options and accessories installed.

This start-up sheet covers all startup check points common to all package equipment. In addition it covers essential startup check points for a number of common installation options. Depending upon the particular unit being started not all sections of this startup sheet will apply. Complete those sections applicable and use the notes section to record any additional information pertinent to your particular installation.

Warranty claims are to be made through the distributor from whom the equipment was purchased.

# EQUIPMENT STARTUP

Use the local LCD or Mobile Access Portal (MAP) Gateway to complete the start-up.

A copy of the completed start-up sheet should be kept on file by the distributor providing the equipment and a copy sent to:

> Johnson Controls/Ducted Systems Technical Services Department 5005 York Drive Norman, OK 73069

> > 1034350-UCL-E-0318

#### SAFETY WARNINGS

The inspections and recording of data outlined in this procedure are required for start-up of Johnson Controls/Ducted Systems' packaged products. Industry recognized safety standards and practices must be observed at all times. General industry knowledge and experience are required to assure technician safety. It is the responsibility of the technician to assess all potential dangers and take all steps warranted to perform the work in a safe manner. By addressing those potential dangers, prior to beginning any work, the technician can perform the work in a safe manner with minimal risk of injury.

# **WARNING**

Lethal voltages are present during some start-up checks. Extreme caution must be used at all times.

# **A**WARNING

Moving parts may be exposed during some startup checks. Extreme caution must be used at all times.

**NOTE:** Read and review this entire document before beginning any of the startup procedures.

# **DESIGN APPLICATION INFORMATION**

This information will be available from the specifying engineer who selected the equipment. If the system is a VAV system the CFM will be the airflow when the remote VAV boxes are in the

full open position and the frequency drive is operating at 60 HZ. Do not proceed with the equipment start-up without the design CFM information.

Design Supply Air CFM: \_\_\_\_\_ Design Return Air CFM:\_\_\_

Return Air CEM.

Design Outdoor Air CFM At Minimum Position:						
Total External Static Pressure:						
Supply Static Pressure:						
Return Static Pressure:						
Design Building Static Pressure:						

ADDITIONAL APPLICATION NOTES FROM SPECIFYING ENGINEER:

**Ducted Systems** 

# REFERENCE

General Inspection	Completed	See Notes
Unit inspected for shipping, storage, or rigging damage		
Unit installed with proper clearances		
Unit installed within slope limitations		
Refrigeration system checked for gross leaks (presence of oil)		
Terminal screws and wiring connections checked for tightness		
Filters installed correctly and clean		
Condensate drain trapped properly, refer to Installation Manual		
All field wiring (power and control) complete		

Refrigerant Line Inspection		System 1		System 2	
Is Condenser below Evaporator?	Yes 🗆	No 🗆	Yes 🗆	No 🗆	
Total Line Length end to end.		Ft.		Ft.	
Vertical Lift in Ft.		Ft.		Ft.	
Vertical Fall in Ft.		Ft.		Ft.	
Number of Elbows?		Ea.		Ea.	
Liquid Line Size	Ea.			Ea.	
Suction Line Size		Ea.		Ea.	
Solenoid Valve?	Yes 🗆	No 🗆	Yes 🗆	No 🗆	
Check Valves?	Yes 🗆	No 🗆	Yes 🗆	No 🗆	
Check Valves / Solenoid arrangements installed as per the Ducted Systems Piping Guide	Yes 🗆	No 🗆	Yes 🗆	No 🗆	
Oil Separator ?	Yes 🗆	No 🗆	Yes 🗆	No 🗆	
Accumulator ?	Yes 🗆	No 🗆	Yes 🗆	No 🗆	
TXV - Hard shutoff	Yes 🗆	No 🗆	Yes 🗆	No 🗆	
Heatpump	Yes 🗆	No 🗆	Yes 🗆	No 🗆	

Air Moving Inspection	Completed	See Notes
Alignment of drive components		
Belt tension adjusted properly		
Blower pulleys tight on shaft, bearing set screws tight, wheel tight to shaft		
Pressure switch or transducer tubing installed properly		

Operating	Measurements	- Air Flow
-----------	--------------	------------

Fan operates with proper rotation (All VFD equipped units with the optional Manua rotation with the Bypass switch set in the LINE position)	al Bypass mus ID Fans □	correct blower Cond. Fans □
Pressure drop across dry evaporator coil (At maximum design CFM) <sup>1</sup>		IWC
External Static Pressure		IWC
Return Static Pressure		IWC
Supply Static Pressure		IWC
Supply Air CFM Using Dry Coil Chart		CFM
Final Adjusted Supply Air CFM <sup>2</sup>		CFM

1. Consult the proper airflow to pressure drop table to obtain the actual airflow at the measured pressure differential.

2. Was a motor pulley adjustment or change required to obtain the correct airflow?

Was it necessary to increase of decrease the airflow to meet the design conditions?

If the motor pulley size was changed, measure the outside diameters of the motor and blower pulleys and record those diameters here;

Blower Motor HP	 FLA	RPM

Pulley Pitch Diameter \_\_\_\_\_\_Turns Out \_\_\_\_\_ Final Turns Out \_\_\_\_\_

Blower Pulley Pitch Diameter \_\_\_\_\_ Fixed Sheave\_\_\_\_\_

#### **ELECTRICAL DATA**

T1 - T2	_ Volts	Т2 - Т3	_ Volts
Control Voltage	Volts	T1 - T3	_ Volts

Device	Nameplate	Measured List All Three Amperages
Supply Fan Motor <sup>1,2</sup>	AMPS	AMPS
Condenser Fan #1	AMPS	AMPS
Condenser Fan #2 (if equipped)	AMPS	AMPS
Condenser Fan #3 (if equipped)	AMPS	AMPS
Condenser Fan #4 (if equipped)	AMPS	AMPS
Compressor #1	AMPS	AMPS
Compressor #2 (if equipped)	AMPS	AMPS
Compressor #3 (if equipped)	AMPS	AMPS
Compressor #4 (if equipped)	AMPS	AMPS

1. VAV units with heat section - simulate heat call to drive VAV boxes and VFD/IGV to maximum design airflow position.

 VAV units without heat section - VAV boxes must be set to maximum design airflow position. Notes above apply for 3rd party application only.

# **OPERATING MEASUREMENTS - COOLING**

Stage	Discharge Pressure	Discharge Temp.	Liquid Line Pressure At Service Valve	Liquid Line Temp. <sup>1</sup>	Subcooling <sup>2</sup>	Suction Pressure	Suction Temp.	Superheat
First <sup>3</sup>	#	0	#	0	0	#	0	0
Second (if equipped)	#	0	#	0	0	#	0	0
Third (if equipped)	#	0	#	0	0	#	0	0
Fourth (if equipped)	#	0	#	0	0	#	0	0
Heat Pump 1st Stage	#	0	#	0	0	#	0	0

1. Liquid line temperature should be taken before filter/drier.

2. Subtract 10 psi from discharge pressure for estimated liquid line pressure

3. If Rawal valve installed, contact Technical Service.

Outside air temperature	db °F	wb °F	RH%
Return Air Temperature	db °F	wb °F	RH%
Mixed Air Temperature	db °F	wb °F	RH%
Supply Air Temperature	db °F	wb °F	RH%

# **REFRIGERANT SAFETIES**

Action	Completed	See Notes
Prove Compressor Rotation (3 phase only) by guage pressure		
Prove High Pressure Safety, All Systems		
Prove Low Pressure Safety, All Systems		

# **OPERATING MEASUREMENTS ELECTRIC HEATING**

Heater kW	kW	Heater Vo	Itage, Nameplate	Volts	
Heater Model Number:					
Serial Number:					
Heater	Nameplate	Meas	Measured List All Three Amperages		
Stage 1	AMPS	AMPS	AMPS	AMPS	
Stage 2	AMPS	AMPS	AMPS	AMPS	
Stage 3	AMPS	AMPS	AMPS	AMPS	
Stage 4	AMPS	AMPS	AMPS	AMPS	
Checked Heater Limit			Yes 🗆	No 🗆	
Air Moving Switch Installed?			Yes 🗆	No 🗆	

# **OPERATIONAL MEASUREMENTS - STAGING CONTROLS**

Verify Proper Operation of Heating/Cooling Staging Controls				
Create a cooling demand at the Thermostat, BAS System or Smart Equipment™ Verify that cooling/economizer stages are energized.				
Create a heating demand at the Thermostat, BAS System or Smart Equipment™ Verify that heating stages are energized.				
Verify Proper Operation of the Variable Frequency Drive (If Required)				
Verify that motor speed modulates with duct pressure change.				

# **FINAL - INSPECTION**

Verify that all operational control set points have been set to desired value Scroll through all setpoints and change as may be necessary to suit the occupant requirements.	
Verify that all option parameters are correct Scroll through all option parameters and ensure that all installed options are enabled in the software and all others are disabled in the software. (Factory software settings should match the installed options)	
Verify that all access panels have been closed and secured	
Save a backup file from the unit control board onto a USB flash drive.	

# **OBSERVED PRODUCT DEFICIENCIES & CONCERNS:**

Subject to change without notice. Printed in U.S.A. Copyright @ 2019 by Johnson Controls, Inc. All rights reserved.

5734682-YIM-B-0519 Supersedes: 5734682-YIM-A-0419

York International Corporation 5005 York Drive Norman, OK 73069