# **DEFLECTION PATTERNS**

# MSR, AMSR, MASR, AMASR Series

#### Notes:


- Patterns are shown in plan view (looking down into inlet)
- Louvers are spaced on 1-1/2" centers
- The core louvers have a 1/4" horizontal lip on all sides that provide a horizontal air pattern which is tight to the ceiling




### Pattern Codes

Code	Deflection Pattern
1SQ	1-way Square
1RL	1-way Recatangular Long
1RS	1-way Rectangular Short
2SQ	2-way Square
2RL	2-way Rectangular long
2CS	2-way Corner Square
2CR	2-way Corner Right
2CL	2-way Corner Left
3SQ	3-way Square
3RL	3-way Rectangular Long
3RS	3-way Rectangular Short
4SQ	4-way Rectangular
4RT	4-way Rectangular

# M Series Snap-In Core Detail







The "M" Series snap-in core is ideal where no screws are required. Core is held in place by two tabs which slide into the outer margin. The other side is secured by a positive lock arrangement. Core is easily removed by releasing lock and removing the core.

- 1. Remove shipping clips.
- 2. Push core sideways.
- 3. Hold core securely and allow core to drop down.

#### **Deflection Patterns**


#### 1 Way




#### 2 Way Opposite



## 2 Way Diagonal



#### 3 Way



### 4 Way

